



SPX Corporation
655 Eisenhower Drive
Owatonna, MN 55060-0995 USA
Phone: (507) 455-7000
Tech. Serv.: (800) 533-6127
Fax: (800) 955-8329
Order Entry: (800) 533-6127
Fax: (800) 283-8665
International Sales: (507) 455-7223
Fax: (507) 455-7063


Form No. 524678

**Parts List &
Operating Instructions**
for:

**1507A
1511A**

Air-Assist Service Jack

Max. Capacity: 5 and 10 Tons



Sheet No. 1 of 3

Issue Date: Rev. G, May 30, 2007

Parts List

Item No.	Qty.	Description	Item No.	Qty.	Description	Item No.	Qty.	Description
1	1	Frame	38	1	Steel Ball	74	1	Spring
2	2	Front Wheel	39	1	Ball Seat	75	1	Universal Joint Assy.
3	2	Washer	40	1	Spring	76	1	Convey Rod
4	4	Snap Ring	41	1	Screw	77	1	Washer
5	3	Grease Fitting	42	1	Sealing Washer	78	2	Pin
6	2	Rod Link	43	1	Bolt	79	2	Copper Washer
7	2	Bolt	44	1	Steel Ball	80	1	Oil Valve Assembly
8	1	Saddle	45	1	Copper Washer	81	1	Nylon Gasket
9	2	Lockwasher	46	1	Bolt	82	1	Pump Cylinder
10	2	Nut	47	1	Steel Ball	83	1	Oil Seal
11	1	Spring	48	1	O-ring	84	1	Washer
12	4	Bolt	49	1	O-ring	85	1	Copper Washer
13	1	Bolt	50	1	Release Valve Rod	86	1	Nut
14	4	Snap Ring	51	1	Pin	87	8	Bolt
15	2	Shaft	52	2	Copper Washer	88	1	Front Cover
16	2	Rear Wheel	53	1	Oil Valve Assembly	89	4	Steel Ball
17	4	Nut	54	1	Nylon Gasket	90	1	Air Pump Housing
18	2	Snap Ring	55	1	Cylinder Pump	91	1	Nut
19	1	Shaft	56	2	O-ring	92	1	Spring
20	1	Washer	57	2	Washer	93	1	Washer
21	1	Pin	58	1	Pin	94	1	Cylinder Pump Plunger
22	1	Connecting Bar	59	1	Cylinder Pump Plunger	95	1	Piston Body "A"
23	1	Spring	60	1	Handle Socket	96	1	O-ring
24	2	Snap Ring	61	1	Pedal	97	1	Air Release Rod
25	1	Shaft	62	1	Nut	98	2	O-ring
26	1	Cover Board	63	1	Washer	99	1	Piston Body "B"
27	1	Snap Ring	64	1	Bolt	100	3	Bolt
28	2	Washer	65	1	Handle	101	1	Air Seal
29	1	O-ring	66	2	Sleeve	102	2	O-ring
30	1	Piston Rod	67	1	Knob	103	1	O-ring
31	1	Piston Ring	68	1	Pin	104	1	Rear Cover
32	1	Sealing Washer	69	1	Control Rod	105	1	Snap Ring
33	1	O-ring	70	1	Spring	106	2	O-ring
34	1	O-ring Retainer	71	3	Washer	107	1	Bolt
35	1	Snap Ring	72	3	Screw	108	1	Air Valve
36	1	Oil Cylinder Assembly	73	1	Rod Joint	109	1	Handle Assembly
37	1	Oil Filler Plug						

Shaded areas reflect the latest revisions made to this form.

Replacement Kits

Kit numbers followed by an asterisk (*) are used on 1507A units only.

Kit numbers followed by a triangle (▲) are used on 1511A units only.

Item No.	Qty.	Description
Air Hose / Air Valve Kit No. 524986		
105	1	Snap Ring
106	2	O-ring
107	1	Bolt
108	1	Air Valve
Air Motor Kit No. 531865		
79	2	Copper Washer
80	1	Oil Valve Assembly
81	1	Nylon Gasket
82	1	Pump Cylinder
83	1	Oil Seal
84	1	Washer
85	1	Copper Washer
86	1	Nut
87	8	Bolt
88	1	Front Cover
89	4	Steel Ball
90	1	Air Pump Housing
91	1	Nut
92	1	Spring
93	1	Washer
94	1	Cylinder Pump Plunger
95	1	Piston Body "A"
96	1	O-ring
97	1	Air Release Rod
98	2	O-ring
99	1	Piston Body "B"
100	3	Bolt
101	1	Air Seal
102	2	O-ring
103	1	O-ring
104	1	Rear Cover
105	1	Snap Ring
106	2	O-ring
107	1	Bolt
108	1	Air Valve

Caster Kit No. 520775* or 520776▲		
16	1	Rear Wheel
17	2	Nut

Foot Pedal Kit No. 520791		
61	1	Pedal

Grease Fitting Kit No. 520796		
5	1	Grease Fitting

Handle Kit No. 524984		
109	1	Handle Assembly

Handle Pivot Kit No. 520790		
18	2	Snap Ring
19	1	Shaft
60	1	Handle Socket

Handle Retaining Bolt Kit No. 520792		
62	1	Nut
63	1	Washer
64	1	Bolt

Item No.	Qty.	Description
Handle Return Spring Kit No. 520793		
23	1	Spring
Hydraulic and Air Motor Seal Kit No. 531857* or 531858▲		
28	2	Washer
29	1	O-ring
32	1	Sealing Washer
33	1	O-ring
34	1	O-ring Retainer
37	1	Oil Filler Plug
42	1	Sealing Washer
45	1	Copper Washer
48	1	O-ring
49	1	O-ring
52	2	Copper Washer
54	1	Nylon Gasket
56	2	O-ring
57	2	Washer
79	2	Copper Washer
80	1	Oil Valve Assembly
81	1	Nylon Gasket
83	1	Oil Seal
84	1	Washer
85	1	Copper Washer
96	1	O-ring
98	2	O-ring
101	1	Air Seal
102	2	O-ring
103	1	O-ring
106	2	O-ring

Hydraulic Unit No. 531859* or 531860▲		
13	1	Bolt
27	1	Snap Ring
28	2	Washer
29	1	O-ring
30	1	Piston Rod
31	1	Piston Ring
32	1	Sealing Washer
33	1	O-ring
34	1	O-ring Retainer
35	1	Snap Ring
36	1	Oil Cylinder Assembly
37	1	Oil Filler Plug
38	1	Steel Ball
39	1	Ball Seat
40	1	Spring
41	1	Screw
42	1	Sealing Washer
43	1	Bolt
44	1	Steel Ball
45	1	Copper Washer
46	1	Bolt
47	1	Steel Ball
48	1	O-ring
49	1	O-ring
50	1	Release Valve Rod
51	1	Pin
52	2	Copper Washer
53	1	Oil Valve Assembly

Item No.	Qty.	Description
54	1	Nylon Gasket
55	1	Cylinder Pump
56	2	O-ring
57	2	Washer
58	1	Pin
59	1	Cylinder Pump Plunger
79	1	Copper Washer

Inspection Plate Kit No. 520787* or 520788▲		
26	1	Cover Board

Leveling Linkage Arm Kit No. 520785* or 520786▲		
4	2	Snap Ring
6	2	Rod Link
7	2	Bolt
9	2	Lockwasher
10	2	Nut

Lift Arm Return Spring Kit No. 520781* or 520782▲		
11	1	Spring
12	2	Bolt
14	2	Snap Ring
15	1	Shaft

Pump Plunger / Connect Bar Kit No. 531862* or 531863▲		
20	1	Washer
21	1	Pin
22	1	Connecting Bar
24	2	Snap Ring
25	1	Shaft
52	2	Copper Washer
53	1	Oil Valve Assembly
54	1	Nylon Gasket
55	1	Cylinder Pump
56	2	O-ring
57	2	Washer
58	1	Pin
59	1	Cylinder Pump Plunger

Release Valve Kit No. 531864		
47	1	Steel Ball
48	1	O-ring
49	1	O-ring
50	1	Release Valve Rod
51	1	Pin

Saddle Kit No. 520779* or 520780▲		
8	1	Saddle

Wheel Kit No. 520777* or 520778▲		
2	1	Front Wheel
3	1	Washer
4	1	Snap Ring
5	1	Grease Fitting

Safety Precautions

- WARNING:** To prevent personal injury and/or damage to equipment,
- Study, understand, and follow all instructions and safety precautions. If the operator cannot read these instructions, the safety precautions and instructions must be read and discussed in the operator's native language.
 - Before using the service jack to lift a vehicle, refer to the vehicle service manual for recommended lifting surfaces on the vehicle chassis.
 - Wear eye protection that meets ANSI Z87.1 and OSHA standards.
 - Inspect the jack before each use; do not use the jack if it's damaged, altered, or in poor condition.
 - Use the jack for lifting purposes only; use approved safety stands to support the axles before working on the vehicle.
 - Never exceed the rated lifting capacity of the jack.
 - Use the jack on a hard, level surface. The jack must be free to roll without any obstructions while lifting or lowering the vehicle. The wheels of the vehicle must be in the straight-ahead position, and the hand brake must be released.
 - Center the axle on the jack saddle. Off-center loads can damage seals and cause jack failure.
 - Lift only dead weight. Do not move the jack while it is supporting a vehicle.
 - Stay clear of lifted loads. Use approved safety stands to support the axles before making repairs.
 - Do not adjust the safety valve.
 - Lower the jack slowly and carefully while watching the position of the jack saddle.
 - Use only approved hydraulic fluid (Chevron AW Hydraulic Oil MV or equivalent). The use of alcohol, hydraulic brake fluid, or transmission oil could damage seals and result in jack failure.

This guide cannot cover every situation, so always do the job with safety first.

Setup

Assemble the Handle

1. Loosen the bolt (Item 64) on the handle socket (60). *NOTE: Item numbers refer to the parts list on page 1.*
2. Insert the handle.
3. Tighten the bolt.

Air Bleed Instructions

Air can accumulate within a hydraulic system during shipment or after prolonged use. This entrapped air causes the jack to respond slowly or to feel "spongy." To remove the air, follow the instructions for both the manual pump and the air pump:

Bleed Air — Manual Pump

1. Open the release valve by turning the release knob counterclockwise.
2. Pump the jack handle six full strokes.
3. Close the release valve by turning the release knob clockwise.
4. If the jack does not immediately respond to pumping the handle, repeat Steps 1–3.

Bleed Air — Air Pump

1. Place the jack on a level surface.
2. Open the release valve by turning the release knob counterclockwise.
3. Run the air pump for 20 seconds, then close the release valve by turning the release knob clockwise.
4. Pump the jack pedal until the jack reaches its maximum height.
5. Open the release valve by turning the release knob counterclockwise, lower the jack to its minimum height.
6. If the jack does not immediately respond to the air pump, repeat steps 1–5, or follow the priming instructions on the next page.




Figure 1

Air Bleed Instructions *continued* . . .

Priming the Air Pump

If air cannot be bled using the air pump air bleed procedure, the air pump has lost its prime. To prime the pump:

1. Remove the cover board (Item 26).
2. Loosen the bolt (Item 46; also see Figure 2) one-half turn.
3. Close the release valve by turning the release knob clockwise.
4. Run the air pump while repeatedly tightening and loosening the bolt. (A small amount of oil may seep from underneath the bolt during this process).
5. When the piston begins to rise, tighten the bolt.
6. Verify the jack will rise to its full height; add oil to the reservoir if necessary.




Figure 2

Operating Instructions

(Refer to Figure 1)


- Control rod in Position A:** Allows you to pump the jack using the handle.
- Control rod in Position B:** Locks the handle in place in three different positions.

1. Connect the shop air supply to the jack. (Shop air should be clean, dry, and regulated at 85–142 psi.)
2. Turn the release knob completely counterclockwise, and place the control rod in Position A.
3. Position the jack under the vehicle using **the manufacturer’s recommended lifting points on the chassis**. The jack must be free to roll without any obstructions while lifting or lowering the vehicle. The wheels of the vehicle must be in the straight-ahead position, with the emergency brake released.
4. Turn the release knob on the jack completely clockwise. Operate the air valve, pump the jack handle, or pump the foot pedal until the saddle touches the vehicle. Check the placement of the saddle lugs. Finish lifting the vehicle.
5. Place approved safety stands under the vehicle at points that will provide stable support. Before working on the vehicle, **SLOWLY** lower the vehicle onto the safety stands by turning the release knob counterclockwise.

Preventive Maintenance

IMPORTANT: Dirt is the greatest single cause of failure in hydraulic units. Keep the service jack clean and well lubricated to prevent foreign matter from entering the system. If the jack has been exposed to rain, snow, sand, or grit, it must be cleaned before it is used.

1. Store the jack in a well-protected area where it will not be exposed to corrosive vapors, abrasive dust, or any other harmful elements.
2. Refer to the illustration, and regularly (at least once per month) lubricate the moving parts shown.
3. Add grease to upper arm grease nipple (shown) every three months.
4. If necessary, add approved anti-wear hydraulic jack oil. **IMPORTANT: The use of alcohol, hydraulic brake fluid, detergent motor oil, or transmission oil could damage the seals and result in jack failure.**



5. Inspect the jack before each use. Take corrective action if any of the following problems are found:
 - a. cracked or damaged housing
 - b. excessive wear, bending, or other damage
 - c. leaking hydraulic fluid
 - d. scored or damaged piston rod
 - e. malfunctioning swivel heads or adjusting screws
 - f. loose hardware
 - g. modified or altered equipment

Troubleshooting Guide

Repair procedures must be performed in a dirt-free environment by qualified personnel who are familiar with this equipment.

Trouble	Cause	Solution
Jack does not lift	<ol style="list-style-type: none"> 1. Release valve is open. 2. Low/no oil in reservoir. 3. Air-locked system. 4. Load is above capacity of jack. 5. Delivery valve and/or bypass valve not working correctly. 6. Packing worn out or defective. 7. Leak in air line. 8. Inadequate air pressure. 	<ol style="list-style-type: none"> 1. <i>Close release valve.</i> 2. <i>Fill with oil and bleed system.</i> 3. <i>Bleed system.</i> 4. <i>Use correct equipment.</i> 5. <i>Clean to remove dirt or foreign matter. Replace oil.</i> 6. <i>Install seal kit.</i> 7. <i>Locate leak; tighten connections or replace hose.</i> 8. <i>Set air pressure to 85–142 psi.</i>
Jack lifts only partially	<ol style="list-style-type: none"> 1. Not enough oil. 	<ol style="list-style-type: none"> 1. <i>Add oil.</i>
Jack advances slowly	<ol style="list-style-type: none"> 1. Pump not working correctly. 2. Leaking seals. 	<ol style="list-style-type: none"> 1. <i>Install seal kit, or replace power unit.</i> 2. <i>Install seal kit.</i>
Jack lifts load, but doesn't hold	<ol style="list-style-type: none"> 1. Cylinder packing is leaking. 2. Valve not working correctly (suction, delivery, release, or bypass). 3. Air-locked system. 	<ol style="list-style-type: none"> 1. <i>Install seal kit.</i> 2. <i>Inspect valves. Clean and repair seat surfaces.</i> 3. <i>Bleed system.</i>
Jack leaks oil	<ol style="list-style-type: none"> 1. Worn or damaged seals. 	<ol style="list-style-type: none"> 1. <i>Install seal kit.</i>
Jack will not retract	<ol style="list-style-type: none"> 1. Release valve is closed. 	<ol style="list-style-type: none"> 1. <i>Open or clean release valve.</i>
Jack retracts slowly	<ol style="list-style-type: none"> 1. Cylinder damaged internally. 2. Link section is binding. 	<ol style="list-style-type: none"> 1. <i>Send jack to OTC authorized service center for repair.</i> 2. <i>Lubricate link section.</i>
Air motor won't run or runs erratically	<ol style="list-style-type: none"> 1. Leak in air line. 2. Inadequate air pressure. 3. Air piston is sticking. 	<ol style="list-style-type: none"> 1. <i>Locate leak, tighten connections, or replace hose.</i> 2. <i>Set air pressure to 85–142 psi.</i> 3. <i>Lube air motor by adding a small amount of oil to jack's air inlet.</i>

Refer to any operating instructions included with the product for detailed information about operation, testing, disassembly, reassembly, and preventive maintenance.

Items found in this parts list have been carefully tested and selected by OTC. **Therefore: Use only genuine OTC replacement parts.**

Additional questions can be directed to our Technical Service Dept.