

VEHICLE COVER FITTING GUIDE

VEHICLE COVER FITTING GUIDE		POLYPRO™ 1	POLYPRO™ 3	DELUXE FOUR LAYER
HATCHBACK/CROSSOVERS	COMPACT UP TO 162"L EXAMPLES: Suzuki SX4, Hyundai Accent 3dr	10-007-021001-00		
	MID SIZE 163" - 175"L EXAMPLES: Toyota Prius, Honda Insight	10-008-031001-00		
	FULL SIZE 176" - 190"L EXAMPLES: Toyota Venza, Subaru Outback	10-009-041001-00		
SEDANS	COMPACT ² UP TO 175"L EXAMPLES: Chevy Aveo, Ford Focus	10-011-241001-00	10-016-241001-00	71003-C
	MID SIZE ² 176" - 190"L EXAMPLES: Honda Accord*, Toyota Camry*	10-012-251001-00	10-013-251001-00	71003-M
	FULL SIZE ² 191" - 210"L EXAMPLES: Lexus LS 460, Mercedes S class	10-010-051001-00	10-014-261001-00	71003-F
SUVS/PICKUPS	COMPACT UP TO 187"L EXAMPLES: Ford Escape, Ford Ranger	10-015-161001-00	10-018-241001-00	
	FULL SIZE ¹ 188" - 230"L* EXAMPLES: Chevy Suburban, Ford F150	10-017-241001-00	10-019-261001-00	
	CREW CAB PICKUP 231" - 261"L EXAMPLES: Ford 350 Long Bed Crew Cab, Dodge Ram Long Bed Quad Cab	10-021-261001-00		
JEEPS	JEEP UP TO 161"L 65"W EXAMPLES: Jeep Wrangler		10-020-251001-00	

*Certain models may vary in size from year to year.

¹May not fit extended cab versions of some models.

²Note: Not recommended for station wagons.