



Bath Tub Mat User's Manual

Tub Surface Preparation

To make sure your newly purchased bath mat stays securely in place, it's important to properly clean the surface of your tub. Your geographical location, your family's bathing habits, and the hardness of your water can all have an effect on how well bathroom products stay put in your bathtub or shower.

1. Clean your tub as you normally would. Make sure not to use a silicon based cleaning solution.
2. Thoroughly dry your tub, either by air or using a dry towel.
3. Wipe down your tub using rubbing alcohol and allow it to completely air dry.

TIPS:

Allow at least 4 hours to dry before using the tub. If possible, we recommend waiting a full 24 hours before using your tub.

Some bath oils can be harmful to the adhesive, making it more likely for treads or appliques to start peeling over time. To minimize this, make sure to pour all oils into a tub already filled with water.

How To Clean Your Bath Mat

All ABELE™ bath mats are easy to remove from your tub or shower for easy cleaning. If you are looking for tips on how or how often you should clean your mat then read on. You'll learn how to properly clean for your vinyl, rubber or TPR bath mat. There are several reasons to keep a clean bath mat, which includes drying it between uses. The last thing you want is to see is soap scum build-up or mineral residue from your water.

1. After each bath or shower peel up the bath mat.
2. Thoroughly rinse the bath mat making sure to get all the soap suds and residue off.
3. Hang up the mat to dry.

About Bath Mat Materials

Rubber Mats - come with very light natural rubber smell, which goes away in a day or two.

Vinyl - ABELE™ vinyl bath mats use the best vinyl material in the industry to manufacture, making our products virtually odorless.

Thermalplastic Rubber (TPR) - have the properties and performance of rubber, but are processed like plastic. They provide excellent flexibility that pure rubber does not.