

267

Brackets for 202T

Please Read Carefully!



BEFORE BEGINNING

Identify and verify that you have all the parts listed. Read thru the instructions at least once, familiarizing yourself with the parts and their use before proceeding. You'll need a #3 Phillips screwdriver and a 7/16" wrench for assembly. These brackets are designed to attach to our 202 Router Fence.

ASSEMBLY & USE

Install a washer (*WS002*) on the each of the 1-1/4" bolts (*HB040*), insert the bolt thru the hole in each of the Arms (*267A*) and start an oval nut (*5760B - flat side first*) on the end of each bolt. *See fig. 1.*

Slide a Clamp Bracket (*267B*) on to the oval nut at the end of each Arm. Center & square it on the Arm and tighten the bolt. *See fig. 1.*

Insert the four 3/4" flat head screws (*MF010*) thru the countersunk holes in the base of the 202 Router Fence and start an oval nut (*5760B - flat side first*) on the end of each screw. Slide each Arm assembly onto the oval nuts, square it to the Router Fence base and tighten the 3/4" screws. *See fig. 2.*

Using your own clamps, clamp the Clamp Brackets to your table saw fence and use it to position and lock the 202T Router Fence in place. *See fig. 3.*

©Copyright WOODHAVEN INC. 11/8/10
(800) 344-6657 or www.woodhaven.com

Parts List:

Part	Description	Qty
267A	Arms - pair, L & R.....	1
267B	Clamp Bracket.....	2
HB040	1-1/4" Bolt.....	2
WS002	Washer.....	2
5760B	Oval Nuts.....	6
MF010	1/4-20 x 3/4" flat head screw.....	4

