



WOODHAVEN

Identify and verify that you have all the parts listed. You'll need a #3 Phillips screwdriver for assembly.

Install a washer (**WB002**) on the 1-1/4" screws (**5776B**), insert the screws thru the holes in the MDF Table (**1828B**) and start an oval nut (**5760B**) on the ends of the screws. Slide the double track (**1826A**) on to the oval nuts, center it end-to-end and flush with the edge of the MDF table and tighten the screws. *See fig. 1.*

Install a washer (**WB002**) on the 2" screw (**MP200**), insert the screw thru the hole in the double track and start an oval nut (**5760B**) on the end of the screw. Slide the oval nut on to the rear T-slot of your 1827 or 1827XL Drill Press Fence, position it where desired and tighten the screw. *See fig. 2.*

©Copyright WOODHAVEN INC. 9/24/07
 (800) 344-6657 or WWW.WOODHAVEN.COM

1828 Table Extension Please Read Carefully!

Parts List:

Part	Description	Quantity
1828A	Double Track	1
1828B	MDF Table.....	1
5760B	Oval Nut	3
WB002	Washer	3
MP200	2" Screw	1
5776B	1-1/4" Screw.....	2

