



WOODHAVEN

BEFORE BEGINNING

Identify and verify that you have all the parts listed. Read thru the instructions at least once, familiarizing yourself with the parts and their use before proceeding. These templates are designed to be used with the 5380 Corner Connectors, Ultra Tracks and our 5301 and/or 5302 Plate Kit. If you do not have these parts, the templates will not work. You'll need a #3 Phillips screwdriver to attach them to the 5380's.

TEMPLATES

Each template is engraved with the part size range it works with (*i.e. 10.5" - 11.5", etc.*). The overall range of part sizes these templates will work on is from 10.5" to 24.5" wide.

Turn Over

5350 & 5360 Door Templates

Please Read Carefully!

Parts List:

Part	Description	Qty
5350	Cathedral Door Templates, set of 10	1
	<i>OR</i>	
5360	Arched Door Templates, set of 10	1
	<i>PLUS:</i>	
5521	Knob	2
WS002	Washer	2
5775B	1/4-20 x 5/8" screw	2
HB020	1/4-20 x 3/4" bolt	2
BUSH050	3/4" OD x 3/8" long spacer	2

1



5360



5350

ATTACH TEMPLATE TO 5380'S

Select the template you wish to use, center it between the Ultra Tracks and attach it to two of the 5380 Corner Connectors using two washers (*WS002*) and two 5/8" screws (*5775B*).

Longer templates tend to flex during use. To prevent this, insert the hex head of the two 3/4" bolts (*HB020*) in the center T-slot of the Ultra Track next to the template. Install a 3/8" long spacer (*BUSH050*) and knob (*5521*) on the end of each bolt, position the bolts/spacers so they provide support for the outer edge of the template, then tighten the knobs. *See fig. 2.*

USING THE TEMPLATES

Follow the edge of the template with 5301 or 5302 Plate Kit to cut the cathedral or arched profile shape in the work. *See below.*

©Copyright WOODHAVEN INC. 1/12/12
(800) 344-6657 or WWW.WOODHAVEN.COM

