

Quick Start Assembly/Install Instructions

CLEARSTREAM™ STM-715 and STM-1000

Before attaching the antenna to any surface, TEST RECEPTION in that area.

Connect the antenna to the TV or receiver and run a full channel scan.
If reception is not as desired, move the antenna and rescan TV/receiver.

Tools Required: Power Drill, 3/16" Drill Bit,
8 and 10mm Ratcheting Drivers, Medium-sized Cross Point Screwdriver.
Before beginning assembly, make sure all pieces needed are present.

A		1/4" x 12mm	2
B		1/4" Hex Nut	3
C		1/4" x 60mm	1
D		1/4" x 50mm Mounting Bolt	4
E		Roof Sealing Pads	4

