

How to select the lug nut or wheel lock for your vehicle in 2 easy steps.

REMEMBER THIS IS ONLY A GUIDE!

ATTENTION: The information provided is **ONLY** a guide. To insure proper lug nut, lug bolt or wheel lock selection, refer to your current lug nut to determine correct lug nut style and thread size for your vehicle.

STEP 1 Determine the seat type of your lug nut for your wheels. Match your lug nut with the charts below, finding the proper seat type. If possible, compare to an actual lug nut from your vehicle for comparison.

Cone Seat

All Acorn lug nuts have a 60° conical seat.

Different types of cone seat lug nuts

ACORN BULGE ACORN ACORN OPEN END DUPLEX ACORN

Mag Seat

Mag lug nuts have a flat seat and use a washer.

Different types of mag seat lug nuts

STANDARD MAG DUPLEX MAG SHORT SHANK CRAGAR SST

(Step 1 continued on next page)

For information about our additional products visit us online at: www.gorilla-auto.com

Lug Bolt Reference Chart

To insure proper lug bolt or lug bolt lock selection, refer to your lug bolt to determine: SEAT TYPE, THREAD SIZE AND THREAD LENGTH.

When selecting lug bolts, reference the following:

- Seat type - Ball or Cone
- Thread size
- Thread length

Ball Seat Lug Bolt Cone Seat Lug Bolt

STEP 2 Determine the correct thread size for your vehicle. Find the thread size listed in this application guide with the make, model and year of your vehicle.

PASSENGER CAR APPLICATIONS			PASSENGER CAR APPLICATIONS		
MAKE AND MODEL	YEAR	THREAD SIZE	MAKE AND MODEL	YEAR	THREAD SIZE
ACURA			BUICK (continued)		
RL	05-Present	14 x 1.50	Riviera	79-99	12 x 1.50
TL	09-Present	14 x 1.50	Roadmaster	91-96	12 x 1.50
All Others	86-Present	12 x 1.50	Skyhawk	75-81	7/16
AMERICAN MOTORS			Skyhawk	82-89	12 x 1.50
All Others	60-87	1/2	Skylark	62-79	7/16
Alliance/Encore	83-87	12 x 1.50	Skylark	80-97	12 x 1.50
BUICK			Somerset	85-87	12 x 1.50
Apollo	73-75	7/16	Verano	12-Present	12 x 1.50
Century	73-81	7/16	CADILLAC		
Century	82-05	12 x 1.50	Allante	87-93	12 x 1.50
Electra	60-84	1/2	Brougham	87-90	1/2
Electra	85-90	12 x 1.50	Brougham	91-95	12 x 1.50
Lacrosse	05-09	12 x 1.50	*CTS, CTS-V*	03-07	12 x 1.50
Lacrosse	10-Present	14 x 1.50	*CTS, CTS-v*	08-Present	14 x 1.50
LeSabre	60-76	1/2	Cimarron	81-88	12 x 1.50
LeSabre	77-85	7/16	DTS	06-11	12 x 1.50
LeSabre	86-05	12 x 1.50	Deville	62-84	1/2
Luxury	05-Present	12 x 1.50	Deville	85-05	12 x 1.50
			Escalade	05-09	1/2

ATTENTION: The information provided is **ONLY A GUIDE.**

To insure proper lug nut or lug bolt selection, refer to your current lug nut to determine correct lug nut style and thread size.

Make	Model	Year	Thread Size	Factory Hex Size	Factory Seat Style
ACURA					
	MDX	02-06	12 x 1.50	3/4" / 19MM	BALL SEAT
	MDX	07-15	14 x 1.50	7/8" / 22MM	BALL SEAT
	RDX	07-15	12 x 1.50	3/4" / 19MM	BALL SEAT
	RL	05-15	14 x 1.50	7/8" / 22MM	BALL SEAT
	TL	09-15	14 x 1.50	7/8" / 22MM	BALL SEAT
	ZDX	10-15	14 x 1.50	7/8" / 22MM	BALL SEAT
	All Other Cars	86-15	12 x 1.50	3/4" / 19MM	BALL SEAT
AMERICAN MOTORS					
	All Others	60-87	1/2	3/4" / 19MM	CONE SEAT
	Alliance/Encore	83-87	12 x 1.50	3/4" / 19MM	CONE SEAT
ASTON MARTIN					
	ALL	04-15	14 x 2.00	13/16" / 21MM	CONE SEAT
AUDI					
	4000	80-87	12 x 1.50	17MM	BALL SEAT BOLT
	5000, Quattro, Coupe	80-87	14 x 1.50	17MM	BALL SEAT BOLT
	A3, A4, A5, A6, A8, Q7, S4, S5, S6, TT	97-15	14 x 1.50	17MM	BALL SEAT BOLT
	All Others	88-96	14 x 1.50	17MM	BALL SEAT BOLT
	Q7	07-15	14 x 1.50	19MM	BALL SEAT BOLT
BMW					
	3 Series	13-15	14 x 1.25	17MM	CONE SEAT BOLT
	4 Series	14-15	14 x 1.25	17MM	CONE SEAT BOLT
	5 Series	12-15	14 x 1.25	17MM	CONE SEAT BOLT
	6 Series	04-10	12 x 1.50	17MM	CONE SEAT BOLT
	6 Series	11-15	14 x 1.25	17MM	CONE SEAT BOLT
	7 Series	02-08	14 x 1.50	17MM	CONE SEAT BOLT
	7 Series	09-15	14 x 1.25	17MM	CONE SEAT BOLT
	X3	04-10	14 x 1.50	17MM	CONE SEAT BOLT
	X3	11-15	14 x 1.25	17MM	CONE SEAT BOLT
	X5	00-06.5	14 x 1.50	19MM	CONE SEAT BOLT
	X5	06.5-15	14 x 1.25	17MM	CONE SEAT BOLT
	X6	08-15	14 x 1.25	17MM	CONE SEAT BOLT
	All Others	77-12	12 x 1.50	17MM	CONE SEAT BOLT
BUICK					
	Apollo	73-75	7/16	3/4" / 19MM	CONE SEAT
	Century	73-81	7/16	3/4" / 19MM	CONE SEAT
	Century	82-06	12 x 1.50	3/4" / 19MM	CONE SEAT

ATTENTION: The information provided is ONLY A GUIDE.

To insure proper lug nut or lug bolt selection, refer to your current lug nut to determine correct lug nut style and thread size.

Electra	60-84	1/2	13/16" / 21MM	CONE SEAT
Electra	85-90	12 x 1.50	3/4" / 19MM	CONE SEAT
Enclave	08-15	14 x 1.50	7/8" / 22MM	CONE SEAT
Lacrosse	05-09	12 x 1.50	3/4" / 19MM	CONE SEAT
Lacrosse	10-15	14 x 1.50	7/8" / 22MM	CONE SEAT
LeSabre	60-76	1/2	3/4" / 19MM	CONE SEAT
LeSabre	77-85	7/16	3/4" / 19MM	CONE SEAT
LeSabre	86-05	12 x 1.50	3/4" / 19MM	CONE SEAT
Lucerne	05-15	12 x 1.50	3/4" / 19MM	CONE SEAT
Opel	68-79	12 x 1.50	3/4" / 19MM	CONE SEAT
Passage CX	08-13	12 x 1.50	3/4" / 19MM	CONE SEAT
Park Avenue	91-05	12 x 1.50	3/4" / 19MM	CONE SEAT
Rainier	04-07	12 x 1.50	3/4" / 19MM	CONE SEAT
Reatta	88-92	12 x 1.50	3/4" / 19MM	CONE SEAT
Regal	77-81	7/16	3/4" / 19MM	CONE SEAT
Regal	82-04	12 x 1.50	3/4" / 19MM	CONE SEAT
Regal	11-15	14 x 1.50	7/8" / 22MM	CONE SEAT
Rendezvous	02-07	12 x 1.50	3/4" / 19MM	CONE SEAT
Riviera	63-78	1/2	3/4" / 19MM	CONE SEAT
Riviera	79-99	12 x 1.50	3/4" / 19MM	CONE SEAT
Roadmaster	91-96	12 x 1.50	3/4" / 19MM	CONE SEAT
Skyhawk	75-81	7/16	3/4" / 19MM	CONE SEAT
Skyhawk	82-89	12 x 1.50	3/4" / 19MM	CONE SEAT
Skylark	62-79	7/16	3/4" / 19MM	CONE SEAT
Skylark	80-97	12 x 1.50	3/4" / 19MM	CONE SEAT
Somerset	85-87	12 x 1.50	3/4" / 19MM	CONE SEAT
Terraza	05-15	12 x 1.50	3/4" / 19MM	CONE SEAT
Verano	12-15	12 x 1.50	3/4" / 19MM	CONE SEAT
CADILLAC				
ATS	13-15	12 x 1.50	3/4" / 19MM	CONE SEAT
Allante	87-93	12 x 1.50	3/4" / 19MM	CONE SEAT
Brougham	87-90	1/2	13/16" / 21MM	CONE SEAT
Brougham	91-95	12 x 1.50	3/4" / 19MM	CONE SEAT
Catera	97-01	12 x 1.50	17MM	CONE SEAT BOLT
CTS, CTS-V	03-07	12 x 1.50	3/4" / 19MM	CONE SEAT
CTS, CTS-v	08-15	14 x 1.50	7/8" / 22MM	CONE SEAT
Cimarron	81-88	12 x 1.50	3/4" / 19MM	CONE SEAT
DTS	06-11	12 x 1.50	3/4" / 19MM	CONE SEAT
Deville	62-84	1/2	13/16" / 21MM	CONE SEAT
Deville	85-05	12 x 1.50	3/4" / 19MM	CONE SEAT

ATTENTION: The information provided is ONLY A GUIDE.

To insure proper lug nut or lug bolt selection, refer to your current lug nut to determine correct lug nut style and thread size.

Eldorado	53-78	1/2	13/16" / 21MM	CONE SEAT
Eldorado	79-02	12 x 1.50	3/4" / 19MM	CONE SEAT
ELR	14-15	12 x 1.50	3/4" / 19MM	CONE SEAT
Escalade, Escalade Hybrid	99-15	14 x 1.50	7/8" / 22MM	CONE SEAT
Fleetwood	60-86	1/2	13/16" / 21MM	CONE SEAT
Fleetwood	85-96	12 x 1.50	3/4" / 19MM	CONE SEAT
Seville	75-76	7/16	3/4" / 19MM	CONE SEAT
Seville	77-79	1/2	13/16" / 21MM	CONE SEAT
Seville	80-04	12 x 1.50	3/4" / 19MM	CONE SEAT
SRX	04-09	12 x 1.50	3/4" / 19MM	CONE SEAT
SRX	10-15	14 x 1.50	7/8" / 22MM	CONE SEAT
XLR, XLR-V, STS	04-11	12 x 1.50	3/4" / 19MM	CONE SEAT
XTS	13-15	14 x 1.50	7/8" / 22MM	CONE SEAT

CHEVROLET

Astro	02-05	14 x 1.50	7/8" / 22MM	CONE SEAT
Astro	85-01	1/2	13/16" / 21MM	CONE SEAT
Avalanche	02-15	14 x 1.50	7/8" / 22MM	CONE SEAT
Aveo	04-11	12 x 1.50	3/4" / 19MM	CONE SEAT
Bel Air, Biscayne	54-70	7/16	3/4" / 19MM	CONE SEAT
Bel Air, Biscayne	71-76	1/2	13/16" / 21MM	CONE SEAT
Beretta	88-96	12 x 1.50	3/4" / 19MM	CONE SEAT
Blazer	92-94	14 x 1.50	7/8" / 22MM	CONE SEAT
Blazer 5 Lug	71-91	1/2	13/16" / 21MM	CONE SEAT
Blazer 6 Lug	71-91	7/16	3/4" / 19MM	CONE SEAT
Camaro	67-81	7/16	3/4" / 19MM	CONE SEAT
Camaro	82-02	12 x 1.50	3/4" / 19MM	CONE SEAT
Camaro	10-15	14 x 1.50	7/8" / 22MM	CONE SEAT
Colorado	04-15	12 x 1.50	3/4" / 19MM	CONE SEAT
Cruze	11-15	12 x 1.50	3/4" / 19MM	CONE SEAT
Caprice	68-76	1/2	3/4" / 19MM	CONE SEAT
Caprice	77-90	7/16	3/4" / 19MM	CONE SEAT
Caprice Wagon	77-90	1/2	13/16" / 21MM	CONE SEAT
Caprice	91-96	12 x 1.50	3/4" / 19MM	CONE SEAT
Cavalier	82-05	12 x 1.50	3/4" / 19MM	CONE SEAT
Celebrity	82-89	12 x 1.50	3/4" / 19MM	CONE SEAT
Chevelle	64-76	7/16	3/4" / 19MM	CONE SEAT
Chevette	76-87	12 x 1.50	3/4" / 19MM	CONE SEAT
Citation	80-85	12 x 1.50	3/4" / 19MM	CONE SEAT
Cobalt	05-11	12 x 1.50	3/4" / 19MM	CONE SEAT
Corsica	88-96	12 x 1.50	3/4" / 19MM	CONE SEAT

ATTENTION: The information provided is ONLY A GUIDE.

To insure proper lug nut or lug bolt selection, refer to your current lug nut to determine correct lug nut style and thread size.

Corvair	60-69	7/16	3/4" / 19MM	CONE SEAT
Corvette	53-83	7/16	3/4" / 19MM	CONE SEAT
Corvette	84-15	12 x 1.50	3/4" / 19MM	CONE SEAT
El Camino	64-81	7/16	3/4" / 19MM	CONE SEAT
El Camino	82-87	12 x 1.50	3/4" / 19MM	CONE SEAT
Equinox	05-09	12 x 1.50	3/4" / 19MM	CONE SEAT
Equinox	10-15	14 x 1.50	7/8" / 22MM	CONE SEAT
Express	96-15	14 x 1.50	7/8" / 22MM	CONE SEAT
HHR	06-11	12 x 1.50	3/4" / 19MM	CONE SEAT
Impala	58-70	7/16	3/4" / 19MM	CONE SEAT
Impala	77-84	7/16	3/4" / 19MM	CONE SEAT
Impala Wagon	77-84	1/2	13/16" / 21MM	CONE SEAT
Impala	94-13	12 x 1.50	3/4" / 19MM	CONE SEAT
Impala	14-15	14 x 1.50	7/8" / 22MM	CONE SEAT
Impala, Bel Air, Biscayne	71-76	1/2	13/16" / 21MM	CONE SEAT
Lumina	89-01	12 x 1.50	3/4" / 19MM	CONE SEAT
Lumina APV	90-96	12 x 1.50	3/4" / 19MM	CONE SEAT
Malibu	82-12	12 x 1.50	3/4" / 19MM	CONE SEAT
Malibu	13-15	14 x 1.50	7/8" / 22MM	CONE SEAT
Monte Carlo	70-81	7/16	3/4" / 19MM	CONE SEAT
Monte Carlo	82-07	12 x 1.50	3/4" / 19MM	CONE SEAT
Monza	75-81	7/16	3/4" / 19MM	CONE SEAT
Nova	86-89	12 x 1.50	13/16" / 21MM	CONE SEAT
Nova, Chevy II	62-79	7/16	3/4" / 19MM	CONE SEAT
S-10	83-04	12 x 1.50	3/4" / 19MM	CONE SEAT
S-10 Blazer	83-05	12 x 1.50	3/4" / 19MM	CONE SEAT
Silverado	99-15	14 x 1.50	7/8" / 22MM	CONE SEAT
Sonic	12-15	12 x 1.50	3/4" / 19MM	CONE SEAT
Sprint	85-93	10 x 1.25	3/4" / 19MM	CONE SEAT
SS	14-15	14 x 1.50	7/8" / 22MM	CONE SEAT
SSR	04-06	12 x 1.50	3/4" / 19MM	CONE SEAT
Suburban 5 Lug	69-70	7/16	3/4" / 19MM	CONE SEAT
Suburban 5 Lug	71-91	1/2	13/16" / 21MM	CONE SEAT
Suburban 6 Lug	69-91	7/16	3/4" / 19MM	CONE SEAT
Suburban 8 Lug	69-91	9/16	7/8" / 22MM	CONE SEAT
Suburban All	92-15	14 x 1.50	7/8" / 22MM	CONE SEAT
Tahoe	95-15	14 x 1.50	7/8" / 22MM	CONE SEAT
Trailblazer	02-09	12 x 1.50	3/4" / 19MM	CONE SEAT
Traverse	08-15	14 x 1.50	7/8" / 22MM	CONE SEAT
Truck 5 Lug	71-87	1/2	13/16" / 21MM	CONE SEAT

ATTENTION: The information provided is ONLY A GUIDE.

To insure proper lug nut or lug bolt selection, refer to your current lug nut to determine correct lug nut style and thread size.

	Truck 6 Lug	65-87	7/16	3/4" / 19MM	CONE SEAT
	Truck 8 Lug	65-87	1/2 or 9/16	7/8" / 22MM	CONE SEAT
	Truck All	88-98	14 x 1.50	7/8" / 22MM	CONE SEAT
	Uplander	05-09	12 x 1.50	3/4" / 19MM	CONE SEAT
	Van 5 Lug	71-96	1/2	13/16" / 21MM	CONE SEAT
	Van 6 Lug	71-96	7/16	3/4" / 19MM	CONE SEAT
	Van 8 Lug	65-96	9/16	7/8" / 22MM	CONE SEAT
	Van 8 Lug	71-96	1/2	7/8" / 22MM	CONE SEAT
	Vega	71-77	7/16	3/4" / 19MM	CONE SEAT
	Volt	11-15	12 x 1.50	3/4" / 19MM	CONE SEAT
CHRYSLER					
	200	11-14	12 x 1.50	13/16" / 21MM	CONE SEAT
	200	2015	12 x 1.25	19MM	CONE SEAT BOLT
	300	05-11	14 x 1.50	13/16" / 21MM	CONE SEAT
	300	12-14	14 x 1.50	7/8" / 22MM	CONE SEAT
	300M	99-04	12 x 1.50	3/4" / 19MM	CONE SEAT
	Aspen	07-09	9/16	7/8" / 22MM	CONE SEAT
	Cirrus	95-00	12 x 1.50	3/4" / 19MM	CONE SEAT
	Concorde	93-04	12 x 1.50	3/4" / 19MM	CONE SEAT
	Cordoba	75-83	1/2	3/4" / 19MM	CONE SEAT
	Crossfire	04-08	12 x 1.50	17MM	BALL SEAT BOLT
	Imperial	81-83	1/2	3/4" / 19MM	CONE SEAT
	Imperial	90-95	12 x 1.50	3/4" / 19MM	CONE SEAT
	Laser	84-86	12 x 1.50	3/4" / 19MM	CONE SEAT
	LeBaron	71-81	1/2	3/4" / 19MM	CONE SEAT
	LeBaron	82-95	12 x 1.50	3/4" / 19MM	CONE SEAT
	LHS	93-01	12 x 1.50	3/4" / 19MM	CONE SEAT
	New Yorker	83-98	12 x 1.50	3/4" / 19MM	CONE SEAT
	New Yorker Fifth Avenue	71-92	1/2	3/4" / 19MM	CONE SEAT
	Newport	71-81	1/2	3/4" / 19MM	CONE SEAT
	Pacifica, PT Cruiser	00-10	12 x 1.50	3/4" / 19MM	CONE SEAT
	Sebring	95-10	12 x 1.50	3/4" / 19MM	CONE SEAT
	Town & Country	82-15	12 x 1.50	3/4" / 19MM	CONE SEAT
DAEWOO					
	Leganza, Nubira, Lanos	99-15	12 x 1.50	3/4" / 19MM	CONE SEAT
DAIHATSU					
	All	91-92	12 x 1.50	3/4" / 19MM	CONE SEAT
DODGE					
	Aries, 400, 600	81-89	12 x 1.50	3/4" / 19MM	CONE SEAT
	Avenger	95-15	12 x 1.50	3/4" / 19MM	CONE SEAT

ATTENTION: The information provided is ONLY A GUIDE.

To insure proper lug nut or lug bolt selection, refer to your current lug nut to determine correct lug nut style and thread size.

Caliber	07-12	12 x 1.50	3/4" / 19MM	CONE SEAT
Caravan/Grand Caravan	84-15	12 x 1.50	3/4" / 19MM	CONE SEAT
Challenger	71-74	1/2	3/4" / 19MM	CONE SEAT
Challenger	78-83	12 x 1.50	13/16" / 21MM	CONE SEAT
Challenger	08-11	14 x 1.50	13/16" / 21MM	CONE SEAT
Challenger	12-14	14 x 1.50	7/8" / 22MM	CONE SEAT
Charger	06-11	14 x 1.50	13/16" / 21MM	CONE SEAT
Charger	12-14	14 x 1.50	7/8" / 22MM	CONE SEAT
Charger	71-76	1/2	3/4" / 19MM	CONE SEAT
Charger	78-88	12 x 1.50	3/4" / 19MM	CONE SEAT
Colt	72-93	12 x 1.50	13/16" / 21MM	CONE SEAT
Conquest	84-88	12 x 1.50	13/16" / 21MM	CONE SEAT
Coronet	71-77	1/2	3/4" / 19MM	CONE SEAT
D50	75-94	12 x 1.50	13/16" / 21MM	CONE SEAT
Dakota	05-11	9/16	7/8" / 22MM	CONE SEAT
Dakota	87-04	1/2	3/4" / 19MM	CONE SEAT
Dart (w/o Disc Brakes)	71-76	7/16	3/4" / 19MM	CONE SEAT
Dart (w/ Disc Brakes)	71-76	1/2	3/4" / 19MM	CONE SEAT
Dart	13-15	12 x 1.25	19MM	CONE SEAT BOLT
Daytona	81-94	12 x 1.50	3/4" / 19MM	CONE SEAT
Diplomat	77-88	1/2	3/4" / 19MM	CONE SEAT
Durango	11-15	14 x 1.50	7/8" / 22MM	CONE SEAT
Durango	04-09	9/16	7/8" / 22MM	CONE SEAT
Durango	98-03	1/2	3/4" / 19MM	CONE SEAT
Dynasty	88-95	12 x 1.50	3/4" / 19MM	CONE SEAT
Intrepid	93-04	12 x 1.50	3/4" / 19MM	CONE SEAT
Journey	09-15	12 x 1.50	3/4" / 19MM	CONE SEAT
Lancer	85-89	12 x 1.50	3/4" / 19MM	CONE SEAT
Magnum	06-09	14 x 1.50	13/16" / 21MM	CONE SEAT
Magnum	71-79	1/2	3/4" / 19MM	CONE SEAT
Mirada	79-83	1/2	3/4" / 19MM	CONE SEAT
Monaco	71-78	1/2	3/4" / 19MM	CONE SEAT
Monaco	90-92	12 x 1.50	3/4" / 19MM	CONE SEAT
Neon	94-05	12 x 1.50	3/4" / 19MM	CONE SEAT
Nitro	07-11	1/2	3/4" / 19MM	CONE SEAT
Omni	78-91	12 x 1.50	3/4" / 19MM	CONE SEAT
Polara	71-73	1/2	3/4" / 19MM	CONE SEAT
Raider	87-89	12 x 1.50	13/16" / 21MM	CONE SEAT
Ram Van	71-15	1/2	3/4" / 19MM	CONE SEAT
Ram Van 2500/3500	94-15	9/16	15/16"	CHECK OEM

ATTENTION: The information provided is ONLY A GUIDE.

To insure proper lug nut or lug bolt selection, refer to your current lug nut to determine correct lug nut style and thread size.

Ramcharger	74-93	1/2	3/4" / 19MM	CONE SEAT	
Rampage	82-84	12 x 1.50	3/4" / 19MM	CONE SEAT	
Ram	72-93	1/2	3/4" / 19MM	CONE SEAT	
Ram 1500	94-01	1/2	3/4" / 19MM	CONE SEAT	
Ram 1500	02-11	9/16	7/8" / 22MM	CONE SEAT	
Ram 1500	12-15	14 x 1.50	7/8" / 22MM	CONE SEAT	
Ram 2500/3500	94-11	9/16	15/16"	CHECK OEM	
Ram 2500/3500	12-15	14 x 1.50	CHECK OEM	CHECK OEM	
Shadow	87-95	12 x 1.50	3/4" / 19MM	CONE SEAT	
Shelby	83-91	12 x 1.50	3/4" / 19MM	CONE SEAT	
Spirit	91-95	12 x 1.50	3/4" / 19MM	CONE SEAT	
St. Regis	79-81	1/2	3/4" / 19MM	CONE SEAT	
Stealth	91-96	12 x 1.50	13/16" / 21MM	CONE SEAT	
Stratus	95-06	12 x 1.50	3/4" / 19MM	CONE SEAT	
Viper	92-10	1/2	3/4" / 19MM	CONE SEAT	
EAGLE					
	All	88-97	12 x 1.50	3/4" / 19MM	CONE SEAT
FORD					
Aerostar	86-97	1/2	3/4" / 19MM	CONE SEAT	
Bronco	66-96	1/2	13/16" / 21MM	CONE SEAT	
Bronco II	83-90	1/2	3/4" / 19MM	CONE SEAT	
C-Max	13-15	12 x 1.50	3/4" / 19MM	CONE SEAT	
Contour	95-00	12 x 1.50	13/16" / 21MM	CONE SEAT	
Courier	77-83	12 x 1.50	13/16" / 21MM	CONE SEAT	
Edge	07-15	1/2	3/4" / 19MM	CONE SEAT	
Escape	01-15	12 x 1.50	3/4" / 19MM	CONE SEAT	
Escort, EXP	84-03	12 x 1.50	13/16" / 21MM	CONE SEAT	
Excursion	00-02	14 x 2.00	13/16" / 21MM	CHECK OEM	
Excursion	03-05	14 x 1.50	13/16" / 21MM	CHECK OEM	
Expedition	97-99	12 x 1.75	3/4" / 19MM	CHECK OEM	
Expedition	00-14	14 x 2.00	13/16" / 21MM	CHECK OEM	
Expedition	2015	14 x 1.50	13/16" / 21MM	CHECK OEM	
Explorer	91-15	1/2	3/4" / 19MM	CONE SEAT	
F-150	97-00	12 x 1.75	13/16" / 21MM	CONE SEAT	
F-150	00.5-14	14 x 2.00	13/16" / 21MM	CONE SEAT	
F-150	2015	14 x 1.50	13/16" / 21MM	CONE SEAT	
F-350 Dually	99-04	14 x 2.00	13/16" / 21MM	CONE SEAT	
F-350 Dually	05-14	14 x 1.50	13/16" / 21MM	CONE SEAT	
Fairlane	55-76	1/2	13/16" / 21MM	CONE SEAT	
Falcon	60-70	1/2	13/16" / 21MM	CONE SEAT	

ATTENTION: The information provided is ONLY A GUIDE.

To insure proper lug nut or lug bolt selection, refer to your current lug nut to determine correct lug nut style and thread size.

Flex	09-15	1/2	3/4" / 19MM	CONE SEAT	
Fiesta	11-15	12 x 1.50	3/4" / 19MM	CONE SEAT	
Five Hundred	05-07	1/2	3/4" / 19MM	CONE SEAT	
Focus	99-15	12 x 1.50	3/4" / 19MM	CONE SEAT	
Freestar, Freestyle	04-09	1/2	3/4" / 19MM	CONE SEAT	
Fusion	06-15	12 x 1.50	3/4" / 19MM	CONE SEAT	
Galaxie	60-64	1/2	13/16" / 21MM	CONE SEAT	
Granada	75-82	1/2	13/16" / 21MM	CONE SEAT	
LTD/Crown Victoria	65-15	1/2	13/16" / 21MM	CONE SEAT	
Maverick	69-77	1/2	13/16" / 21MM	CONE SEAT	
Mustang	65-14	1/2	13/16" / 21MM	CONE SEAT	
Mustang	2015	14 x 1.50	13/16" / 21MM	CONE SEAT	
Pinto	71-80	1/2	13/16" / 21MM	CONE SEAT	
Probe	89-97	12 x 1.50	13/16" / 21MM	CONE SEAT	
Ranger	83-15	1/2	3/4" / 19MM	CONE SEAT	
Superduty (F-250, F-350)	98-02	14 x 2.00	13/16" / 21MM	CONE SEAT	
Superduty (F-250, F-350)	03-15	14 x 1.50	13/16" / 21MM	CONE SEAT	
Taurus	86-06	12 x 1.50	3/4" / 19MM	CONE SEAT	
Taurus	08-15	1/2	3/4" / 19MM	CONE SEAT	
T-Bird	55-88	1/2	13/16" / 21MM	CONE SEAT	
T-Bird	89-06	12 x 1.50	3/4" / 19MM	CONE SEAT	
Tempo	84-94	12 x 1.50	3/4" / 19MM	CONE SEAT	
Torino	68-76	1/2	13/16" / 21MM	CONE SEAT	
Transit Connect	10-15	12 x 1.50	3/4" / 19MM	CONE SEAT	
Truck 5 Lug	55-96	1/2	13/16" / 21MM	CONE SEAT	
Truck 8 Lug	84-98	1/2 or 9/16	7/8" / 22MM	CONE SEAT	
Van 5 Lug	62-15	1/2	7/8" / 22MM	CONE SEAT	
Van 8 Lug	62-15	1/2 or 9/16	7/8" / 22MM	CONE SEAT	
Windstar	94-03	12 x 1.50	3/4" / 19MM	CONE SEAT	
FIAT					
	500 (Including 500e, 500L)	12-15	12 x 1.25	17MM	CONE SEAT BOLT
GEO					
	Metro	90-94	10 x 1.25	3/4" / 19MM	CONE SEAT
	Metro	95-15	12 x 1.25	3/4" / 19MM	CONE SEAT
	Metro (convertible)	90-93	12 x 1.25	3/4" / 19MM	CONE SEAT
	Prizm	90-02	12 x 1.50	13/16" / 21MM	CONE SEAT
	Spectrum	85-89	12 x 1.50	13/16" / 21MM	CONE SEAT
	Storm	90-93	12 x 1.50	3/4" / 19MM	CONE SEAT
	Tracker	89-15	12 x 1.25	3/4" / 19MM	CONE SEAT
GMC					

ATTENTION: The information provided is ONLY A GUIDE.

To insure proper lug nut or lug bolt selection, refer to your current lug nut to determine correct lug nut style and thread size.

Arcadia	08-15	14 x 1.50	7/8" / 22MM	CONE SEAT
Caballero	64-81	7/16	3/4" / 19MM	CONE SEAT
Caballero	82-87	12 x 1.50	3/4" / 19MM	CONE SEAT
Canyon	04-12	12 x 1.50	3/4" / 19MM	CONE SEAT
Censor	08-14	12 x 1.50	3/4" / 19MM	CONE SEAT
Denali	98-15	14 x 1.50	7/8" / 22MM	CONE SEAT
Envoy	99-15	12 x 1.50	3/4" / 19MM	CONE SEAT
Jimmy 5 Lug	69-70	7/16	3/4" / 19MM	CONE SEAT
Jimmy 5 Lug	71-91	1/2	13/16" / 21MM	CONE SEAT
Jimmy 6 Lug	71-91	7/16	3/4" / 19MM	CONE SEAT
S-15, Sonoma, Jimmy	83-15	12 x 1.50	3/4" / 19MM	CONE SEAT
Safari	03-05	14 x 1.50	7/8" / 22MM	CONE SEAT
Safari	85-02	1/2	7/8" / 22MM	CONE SEAT
Savana	96-15	14 x 1.50	7/8" / 22MM	CONE SEAT
Sierra	99-15	14 x 1.50	7/8" / 22MM	CONE SEAT
Suburban 5 Lug	69-70	7/16	3/4" / 19MM	CONE SEAT
Suburban 5 Lug	71-91	1/2	7/8" / 22MM	CONE SEAT
Suburban 6 Lug	71-91	7/16	3/4" / 19MM	CONE SEAT
Suburban 8 Lug	71-91	9/16	7/8" / 22MM	CONE SEAT
Suburban All	92-99	14 x 1.50	7/8" / 22MM	CONE SEAT
Truck	88-98	14 x 1.50	7/8" / 22MM	CONE SEAT
Truck 5 Lug	71-87	1/2	7/8" / 22MM	CONE SEAT
Truck 6 Lug	60-87	7/16	3/4" / 19MM	CONE SEAT
Truck 8 Lug	65-87	1/2	7/8" / 22MM	CONE SEAT
Truck 8 Lug	65-87	9/16	7/8" / 22MM	CONE SEAT
Vandura 5 Lug	71-96	1/2	7/8" / 22MM	CONE SEAT
Vandura 6 Lug	71-96	7/16	3/4" / 19MM	CONE SEAT
Vandura 8 Lug	71-96	1/2	7/8" / 22MM	CONE SEAT
Vandura 8 Lug	71-96	9/16	7/8" / 22MM	CONE SEAT
Terrain	10-15	14 x 1.50	7/8" / 22MM	CONE SEAT
Yukon/Yukon XL	92-15	14 x 1.50	7/8" / 22MM	CONE SEAT
HONDA				
All Cars	83-15	12 x 1.50	3/4" / 19MM	BALL SEAT
Crosstour	10-15	12 x 1.50	3/4" / 19MM	BALL SEAT
CRV	95-15	12 x 1.50	3/4" / 19MM	BALL SEAT
Element	02-15	12 x 1.50	3/4" / 19MM	BALL SEAT
Odyssey	05-15	14 x 1.50	7/8" / 22MM	BALL SEAT
Odyssey, CRV, Passport	94-04	12 x 1.50	3/4" / 19MM	BALL SEAT
Pilot	02-08	12 x 1.50	3/4" / 19MM	BALL SEAT
Pilot	09-15	14 x 1.50	7/8" / 22MM	BALL SEAT

ATTENTION: The information provided is ONLY A GUIDE.

To insure proper lug nut or lug bolt selection, refer to your current lug nut to determine correct lug nut style and thread size.

	Ridgeline	06-15	14 x 1.50	7/8" / 22MM	BALL SEAT
HUMMER					
	Hummer H2	03-15	14 x 1.50	7/8" / 22MM	CONE SEAT
	Hummer H3	06-15	12 x 1.50	3/4" / 19MM	CONE SEAT
HYUNDAI					
	All	86-15	12 x 1.50	13/16" / 21MM	CONE SEAT
INFINITI					
	All	90-15	12 x 1.25	13/16" / 21MM	CHECK OEM
	QX56	11-13	14 x 1.50	13/16" / 21MM	CHECK OEM
	QX80	14-15	14 x 1.50	13/16" / 21MM	CHECK OEM
ISUZU					
	All	83-93	12 x 1.50	3/4" / 19MM	OEM MAG STYLE
JAGUAR					
	All	76-97	1/2	7/8" / 22MM	OEM MAG STYLE
	S Type	99-08	12 x 1.50	3/4" / 19MM	OEM MAG STYLE
	X Type	02-09	12 x 1.50	3/4" / 19MM	OEM MAG STYLE
	XF	08-15	12 x 1.50	3/4" / 19MM	OEM MAG STYLE
	XJ	91-03	1/2	7/8" / 22MM	OEM MAG STYLE
	XJ	04-15	12 x 1.50	3/4" / 19MM	OEM MAG STYLE
	XK8, XKR	97-06	1/2	7/8" / 22MM	OEM MAG STYLE
	XK, XKR	07-15	12 x 1.50	3/4" / 19MM	OEM MAG STYLE
JEEP					
	All 5 Lug	All	1/2	3/4" / 19MM	CONE SEAT
	All 6 Lug	All	7/16	3/4" / 19MM	CONE SEAT
	Compass, Patriot	07-15	12 x 1.50	3/4" / 19MM	CONE SEAT
	Cherokee	14-15	12 x 1.25	19MM	CONE SEAT BOLT
	Grand Cherokee	11-15	14 x 1.50	7/8" / 22MM	CONE SEAT
KIA					
	All	90-15	12 x 1.50	13/16" / 21MM	CONE SEAT
LAND ROVER					
	Discovery, Land Rover	96-04	16 x 1.50	27MM	OEM MAG STYLE
	LR2, LR3, LR4, Range Rover	03-15	14 x 1.50	7/8" / 22MM	OEM MAG STYLE
	Evoque	12-15	14 x 1.50	13/16" / 21MM	CONE SEAT
	Free Lander	02-05	12 x 1.50	13/16" / 21MM	CONE SEAT
LEXUS					
	All Cars (exc. LS460)	90-15	12 x 1.50	13/16" / 21MM	OEM MAG STYLE
	LS460, 460h, 600H	07-15	14 x 1.50	7/8" / 22MM	OEM MAG STYLE
	LX450, GX, RX	97-15	12 x 1.50	13/16" / 21MM	OEM MAG STYLE
	LX470, LX570	98-15	14 x 1.50	7/8" / 22MM	OEM MAG STYLE

ATTENTION: The information provided is ONLY A GUIDE.

To insure proper lug nut or lug bolt selection, refer to your current lug nut to determine correct lug nut style and thread size.

LINCOLN					
	Aviator	03-05	1/2	3/4" / 19MM	CONE SEAT
	Blackwood	02-03	14 x 2.00	13/16" / 21MM	CHECK OEM
	Continental	69-87	1/2	13/16" / 21MM	CONE SEAT
	Continental	88-02	12 x 1.50	3/4" / 19MM	CONE SEAT
	LS	01-06	12 x 1.50	3/4" / 19MM	CHECK OEM
	Mark VIII	93-98	12 x 1.50	3/4" / 19MM	CONE SEAT
	Mark LT	06-08	14 x 2.00	13/16" / 21MM	CHECK OEM
	MKS	09-15	1/2	3/4" / 19MM	CONE SEAT
	MKT, MKX	07-15	1/2	3/4" / 19MM	CONE SEAT
	MKZ	06-15	12 x 1.50	3/4" / 19MM	CONE SEAT
	Navigator	98-99	12 x 1.75	3/4" / 19MM	CHECK OEM
	Navigator	00-14	14 x 2.00	13/16" / 21MM	CHECK OEM
	Navigator	2015	14 x 1.50	13/16" / 21MM	CONE SEAT
	Town Car	84-14	1/2	13/16" / 21MM	CONE SEAT
	Versailles	77-80	1/2	13/16" / 21MM	CONE SEAT
LOTUS					
	All (exc. Evora)	06-14	12 x 1.50	CHECK OEM	CONE SEAT BOLT
	Evora	10-14	12 x 1.50	CHECK OEM	CONE SEAT BOLT
MAZDA					
	All Cars	86-15	12 x 1.50	13/16" / 21MM	CONE SEAT
	MPV	90-06	12 x 1.50	13/16" / 21MM	CONE SEAT
	Navajo	91-95	1/2	3/4" / 19MM	CONE SEAT
	Tribute, CX7, CX9, 5	01-15	12 x 1.50	13/16" / 21MM	CONE SEAT
	Truck B2000, B2200, B2600i	79-93	12 x 1.50	13/16" / 21MM	CONE SEAT
	Truck B2300, B3000, B4000	94-09	1/2	3/4" / 19MM	CONE SEAT
MERCEDES-BENZ					
	C-Class	84-07	12 x 1.50	17MM	BALL SEAT BOLT
	C-Class	08-15	14 x 1.50	17MM	BALL SEAT BOLT
	CL, CLS	97-15	14 x 1.50	17MM	BALL SEAT BOLT
	CLK, SLK	98-15	12 x 1.50	17MM	BALL SEAT BOLT
	E-Class	86-01	12 x 1.50	17MM	BALL SEAT BOLT
	E-Class	02-15	14 x 1.50	17MM	BALL SEAT BOLT
	S-Class	92-15	14 x 1.50	17MM	BALL SEAT BOLT
	SL	94-06	12 x 1.50	17MM	BALL SEAT BOLT
	SL	07-15	14 x 1.50	17MM	BALL SEAT BOLT
	SL AMG	03-15	14 x 1.50	17MM	BALL SEAT BOLT
	G, GL, GLK, ML, R	All	14 x 1.50	17MM	BALL SEAT BOLT
MERCURY					
	Bobcat	75-80	1/2	13/16" / 21MM	CONE SEAT

ATTENTION: The information provided is ONLY A GUIDE.

To insure proper lug nut or lug bolt selection, refer to your current lug nut to determine correct lug nut style and thread size.

Capri	78-86	1/2	13/16" / 21MM	CONE SEAT
Capri	91-94	12 x 1.50	13/16" / 21MM	CONE SEAT
Cougar	67-88	1/2	13/16" / 21MM	CONE SEAT
Cougar	89-02	12 x 1.50	3/4" / 19MM	CONE SEAT
Cyclone	67-71	1/2	13/16" / 21MM	CONE SEAT
Grand Marquis	91-11	1/2	13/16" / 21MM	CONE SEAT
Lynx	84-87	12 x 1.50	3/4" / 19MM	CONE SEAT
Mariner	05-11	12 x 1.50	3/4" / 19MM	CONE SEAT
Marquis	67-90	1/2	13/16" / 21MM	CONE SEAT
Merkur	85-89	12 x 1.50	13/16" / 21MM	CONE SEAT
Milan	06-11	12 x 1.50	3/4" / 19MM	CONE SEAT
Monarch	75-80	1/2	13/16" / 21MM	CONE SEAT
Montclair	60-68	1/2	13/16" / 21MM	CONE SEAT
Montego	05-07	1/2	13/16" / 21MM	CONE SEAT
Montego	68-76	1/2	13/16" / 21MM	CONE SEAT
Monterey	04-07	12 x 1.50	13/16" / 21MM	CONE SEAT
Mountaineer	97-11	1/2	3/4" / 19MM	CONE SEAT
Mystique	95-00	12 x 1.50	3/4" / 19MM	CONE SEAT
Sable	86-05	12 x 1.50	3/4" / 19MM	CONE SEAT
Sable	08-09	1/2	13/16" / 21MM	CONE SEAT
Topaz	84-94	12 x 1.50	3/4" / 19MM	CONE SEAT
Tracer	88-99	12 x 1.50	13/16" / 21MM	CONE SEAT
Zephyr	78-83	1/2	13/16" / 21MM	CONE SEAT
MINI COOPER				
All	02-06	12 x 1.50	17MM	CONE SEAT BOLT
All	07-15	14 x 1.25	17MM	CONE SEAT BOLT
MITSUBISHI				
All (except Raider)	83-15	12 x 1.50	13/16" / 21MM	CHECK OEM
Raider	06-09	9/16	7/8" / 22MM	CHECK OEM
NISSAN/DATSUN				
All (exc. NV 1500, 2500, 3500)	72-15	12 x 1.25	13/16" / 21MM	CHECK OEM
NV 1500, 2500, 3500	12-14	14 x 1.50	13/16" / 21MM	CHECK OEM
OLDSMOBILE				
88	86-99	12 x 1.50	3/4" / 19MM	CONE SEAT
98	60-84	1/2	13/16" / 21MM	CONE SEAT
98	85-96	12 x 1.50	3/4" / 19MM	CONE SEAT
Achieva	92-98	12 x 1.50	3/4" / 19MM	CONE SEAT
Alero	98-04	12 x 1.50	3/4" / 19MM	CONE SEAT
Aurora	95-03	12 x 1.50	3/4" / 19MM	CONE SEAT
Bravada	91-04	12 x 1.50	3/4" / 19MM	CONE SEAT

ATTENTION: The information provided is ONLY A GUIDE.

To insure proper lug nut or lug bolt selection, refer to your current lug nut to determine correct lug nut style and thread size.

Custom Cruiser	81-90	1/2	13/16" / 21MM	CONE SEAT
Custom Cruiser	91-95	12 x 1.50	3/4" / 19MM	CONE SEAT
Cutlass	64-81	7/16	3/4" / 19MM	CONE SEAT
Cutlass	82-99	12 x 1.50	3/4" / 19MM	CONE SEAT
Delta 88	77-85	7/16 or 1/2	13/16" / 21MM	CONE SEAT
Firenza	82-88	12 x 1.50	3/4" / 19MM	CONE SEAT
Intrigue	98-02	12 x 1.50	3/4" / 19MM	CONE SEAT
Omega	73-79	7/16	3/4" / 19MM	CONE SEAT
Omega	80-84	12 x 1.50	3/4" / 19MM	CONE SEAT
Regency	97-98	12 x 1.50	3/4" / 19MM	CONE SEAT
Silhouette	94-04	12 x 1.50	3/4" / 19MM	CONE SEAT
Starfire	75-80	7/16	3/4" / 19MM	CONE SEAT
Toronado	66-78	1/2	13/16" / 21MM	CONE SEAT
Toronado	79-92	12 x 1.50	3/4" / 19MM	CONE SEAT

PLYMOUTH

Acclaim	89-95	12 x 1.50	3/4" / 19MM	CONE SEAT
Arrow	79-83	12 x 1.50	3/4" / 19MM	CONE SEAT
Barracuda	71-76	7/16 or 1/2	3/4" / 19MM	CONE SEAT
Belvedere	71-76	1/2	3/4" / 19MM	CONE SEAT
Breeze	97-01	12 x 1.50	3/4" / 19MM	CONE SEAT
Caravelle	84-89	12 x 1.50	3/4" / 19MM	CONE SEAT
Cricket	All	12 x 1.25	3/4" / 19MM	CONE SEAT
Duster	71-76	7/16 or 1/2	3/4" / 19MM	CONE SEAT
Fury	71-89	1/2	3/4" / 19MM	CONE SEAT
Horizon	78-90	12 x 1.50	3/4" / 19MM	CONE SEAT
Laser	90-94	12 x 1.50	13/16" / 21MM	CONE SEAT
Neon	95-01	12 x 1.50	3/4" / 19MM	CONE SEAT
Reliant	81-89	12 x 1.50	3/4" / 19MM	CONE SEAT
Road Runner	71-76	1/2	3/4" / 19MM	CONE SEAT
Sapporo	All	12 x 1.50	3/4" / 19MM	CONE SEAT
Satellite	71-76	1/2	3/4" / 19MM	CONE SEAT
Sundance	87-94	12 x 1.50	3/4" / 19MM	CONE SEAT
TC3	78-84	12 x 1.50	3/4" / 19MM	CONE SEAT
Trail Duster	71-87	1/2	3/4" / 19MM	CONE SEAT
Turismo	78-88	12 x 1.50	3/4" / 19MM	CONE SEAT
Valiant	71-76	7/16 or 1/2	3/4" / 19MM	CONE SEAT
Volare	76-80	1/2	3/4" / 19MM	CONE SEAT
Voyager Full Size	77-87	1/2	3/4" / 19MM	CONE SEAT
Voyager/Grand Voyager	84-01	12 x 1.50	3/4" / 19MM	CONE SEAT

PONTIAC

ATTENTION: The information provided is ONLY A GUIDE.

To insure proper lug nut or lug bolt selection, refer to your current lug nut to determine correct lug nut style and thread size.

6000	82-92	12 x 1.50	3/4" / 19MM	CONE SEAT
Astire	75-77	7/16	3/4" / 19MM	CONE SEAT
Aztek	01-05	12 x 1.50	3/4" / 19MM	CONE SEAT
Bonneville	60-76	1/2	13/16" / 21MM	CONE SEAT
Bonneville	77-81	7/16 or 1/2	13/16" / 21MM	CONE SEAT
Bonneville	82-05	12 x 1.50	3/4" / 19MM	CONE SEAT
Catalina	60-76	1/2	13/16" / 21MM	CONE SEAT
Catalina	77-81	7/16 or 1/2	3/4" / 19MM	CONE SEAT
Fiero	84-88	12 x 1.50	3/4" / 19MM	CONE SEAT
Firebird	67-81	7/16	3/4" / 19MM	CONE SEAT
Firebird	82-02	12 x 1.50	3/4" / 19MM	CONE SEAT
G3, G5, G6, Solstice	05-10	12 x 1.50	3/4" / 19MM	CONE SEAT
G8	08-09	14 x 1.50	7/8" / 22MM	CONE SEAT
Grand AM	73-84	7/16	3/4" / 19MM	CONE SEAT
Grand AM	85-05	12 x 1.50	3/4" / 19MM	CONE SEAT
Grand Prix	69-81	7/16	3/4" / 19MM	CONE SEAT
Grand Prix	82-08	12 x 1.50	3/4" / 19MM	CONE SEAT
J2000	82-84	12 x 1.50	3/4" / 19MM	CONE SEAT
Lemans	64-81	7/16	3/4" / 19MM	CONE SEAT
Parisienne	83-86	7/16	3/4" / 19MM	CONE SEAT
Phoenix	80-84	12 x 1.50	3/4" / 19MM	CONE SEAT
Safari Wagon	87-88	1/2	3/4" / 19MM	CONE SEAT
Sunbird	76-81	7/16	3/4" / 19MM	CONE SEAT
Sunbird	84-94	12 x 1.50	3/4" / 19MM	CONE SEAT
Sunfire	95-05	12 x 1.50	3/4" / 19MM	CONE SEAT
T1000	82-87	12 x 1.50	3/4" / 19MM	CONE SEAT
Torrent	06-09	12 x 1.50	3/4" / 19MM	CONE SEAT
Trans Sport/Montana, SV6	90-06	12 x 1.50	3/4" / 19MM	CONE SEAT
Ventura	60-77	7/16	3/4" / 19MM	CONE SEAT
Vibe	03-10	12 x 1.50	13/16" / 21MM	OEM MAG STYLE
SAAB				
9-2X	05-06	12 x 1.25	3/4" / 19MM	CONE SEAT
9-5	2011	14 x 1.50	7/8" / 22MM	CONE SEAT
9 3	99-11	12 x 1.50	19MM	CONE SEAT BOLT
9 4	93-98	12 x 1.50	19MM	CONE SEAT BOLT
9 5	99-09	12 x 1.50	19MM	CONE SEAT BOLT
9-7X	05-09	12 x 1.50	3/4" / 19MM	CONE SEAT
9-4X	2011	14 x 1.50	7/8" / 22MM	CONE SEAT
SATURN				
All (Exc. Outlook)	91-09	12 x 1.50	3/4" / 19MM	CONE SEAT

ATTENTION: The information provided is ONLY A GUIDE.

To insure proper lug nut or lug bolt selection, refer to your current lug nut to determine correct lug nut style and thread size.

	Outlook	07-09	14 x 1.50	7/8" / 22MM	CONE SEAT
SCION					
	All	04-15	12 x 1.50	13/16" / 21MM	OEM MAG STYLE
SMART					
	All	08-14	12 x 1.50	17MM	CONE SEAT BOLT
SUBARU					
	All	77-15	12 x 1.25	3/4" / 19MM	CONE SEAT
SUZUKI					
	Forenza, Reno, Verona	04-15	12 x 1.50	3/4" / 19MM	CONE SEAT
	All Others	89-15	12 x 1.25	3/4" / 19MM	CONE SEAT
TESLA					
	Model S	12-14	14 x 1.50	13/16" / 21MM	CONE SEAT
	Roadster	08-12	12 x 1.50	CHECK OEM	CONE SEAT BOLT
TOYOTA					
	All (Exc. Land Cruiser, Tundra)	68-15	12 x 1.50	13/16" / 21MM	OEM MAG STYLE
	Land Cruiser	98-15	14 x 1.50	7/8" / 22MM	OEM MAG STYLE
	Tundra	07-15	14 x 1.50	7/8" / 22MM	OEM MAG STYLE
VOLKSWAGEN					
	All Models - 4 Lug Bolts	75-03	12 x 1.50	17MM	BALL SEAT BOLT
	All Models - 5 Lug Bolts	92-15	14 x 1.50	17MM	BALL SEAT BOLT
	Routan	09-15	12 x 1.50	3/4" / 19MM	CONE SEAT
	Touareg		14 x 1.50	19MM	BALL SEAT BOLT
VOLVO					
	C30	08-15	12 x 1.50	13/16" / 21MM	CONE SEAT
	C70	06-15	12 x 1.50	3/4" / 19MM	CONE SEAT
	S40, V40, V50	95-11	12 x 1.50	13/16" / 21MM	CONE SEAT
	700 and 900 Series, S90, V90	84-98	12 x 1.50	3/4" / 19MM	CONE SEAT
	200 Series	70-93	1/2	3/4" / 19MM	CONE SEAT
	C70	01-04	12 x 1.75	19MM	CONE SEAT BOLT
	C70	2005	14 x 1.50	19MM	CONE SEAT BOLT
	S60	93-15	14 x 1.50	19MM	CONE SEAT BOLT
	V70, XC60, XC70, XR70, S80, XC90	00-15	14 x 1.50	19MM	CONE SEAT BOLT

ATTENTION: The information provided is ONLY A GUIDE.

To insure proper lug nut or lug bolt selection, refer to your current lug nut to determine correct lug nut style and thread size.