

For issues like the DVR just blinks never comes on

Solution: Please use the VGA port and connect to the monitor

For further queries regarding the product Please refer to the manufacture knowledge based article

http://kb.zmodo.com/index.php?solution_id=1360

Avail technical support at **217-903-5037**. You can also reach out at **866 551-6881** ext **8117** or ext **2502**

For instruction video and user guide .Kindly refer below

Knowledge base for easy to use: <http://kb.zmodo.com/>

YouTube videos

<https://www.youtube.com/channel/UCcvcy5EbVf76-GXUNi9hgfQ/videos>