


---


## ASUS ZenWatch firmware update SOP

### System update steps:

#### 1. Enter [Settings]



#### 2. Press [About]



#### 3. Press [System updates], and follow the system message to update system.

**PS: please make sure Zenwatch and your phone are connected via BT, and your phone has wifi connection.**

