




WWW.SMITTYBILT.COM

## WINCH WIRING SUPPLEMENT

**Please notice the following in regards to wiring the XRC8 and XRC10 winches. Connecting the wires in any other configuration may cause the winch to perform incorrectly or cause damage to the winch or ISM. Proper connections are essential to having the winch operate at the optimal level without causing any damage to the winch.**



**Pay close attention to proper electrical cable connection as follows.**

1. Short red cable (B') connecting to the red terminal (B) of the motor.
2. Short black cable with yellow jacket (C') connecting to the yellow terminal (C) of the motor.
3. Short black cable with black jacket (D') connecting to the black terminal (D) of the motor.
4. Thin black cable (a') connecting to bottom terminal (A) of the motor.
5. Long black cable (1.8m), one terminal (A') connecting to the bottom terminal (a) of the motor, and the other terminal negative (-) connecting to negative (-) terminal of battery.
6. Long red cable positive (+) connecting to positive (+) terminal of battery.


**For Technical Support/Warranty Information please call 310-762-9944**

**Smittybilt, 400 West Artesia Blvd, Compton, CA 90220**



WWW.SMITTYBILT.COM

## WINCH WIRING SUPPLEMENT



The Control box short red cable connects to Terminal (B) on the back of the motor.

The Control box short black cable with BLACK protective cover connects to Terminal (D) on the back of the motor.

The Control box short black cable with YELLOW protective cover connects to Terminal (C) on the back of the motor.



The Control box long red cable connects to the positive terminal on the vehicles battery.

The Control box thin black wire mounts to terminal (A) on the bottom of the motor along with the enclosed separate 4 gauge wire that connects to the negative terminal on the vehicle battery.


For Technical Support/Warranty Information please call 310-762-9944

Smittybilt, 400 West Artesia Blvd, Compton, CA 90220



WWW.SMITTYBILT.COM

## WINCH WIRING SUPPLEMENT



For Technical Support/Warranty Information please call 310-762-9944

Smittybilt, 400 West Artesia Blvd, Compton, CA 90220