




Quickstart Guide

StreamHD Mac Edition – SWP130A

1. SOFTWARE INSTALLATION:

Prior to installing the Warpia StreamHD software it is important to make sure there is no prior installation of Wireless USB or Display Link software from Warpia or other companies. IF YOU HAVE THIS SOFTWARE IN YOUR SYSTEM, THIS WILL CAUSE THE STREAMHD SOFTWARE TO NOT WORK PROPERLY.

If you see either Wireless USB or Display Link programs, first uninstall them before continuing. Next, Insert the StreamHD installation CD into the PC and begin the software installation by running the Warpia UWB Installer file. Ensure that the PC Adapter is NOT plugged into the PC at this time.



2. HARDWARE INSTALLATION:


After the software has been installed, insert PC Adapter into an available USB port.



Plug the Receiver Base into an electrical outlet using the power cord provided.



Connect the Receiver Base to the TV/Monitor/Projector using an HDMI or VGA cable with the appropriate sound cable when required. (cables not included)



3. ESTABLISHING INITIAL WIRELESS CONNECTION WITH TV/MONITOR/PROJECTOR:

Open the **UWB Connection Manager** by clicking on the black **UWB Connection Manager** icon located in the top Menu Bar of your desktop.






Move the cursor over the StreamHD Device Icon and double click to establish a connection




When the wireless connection has been made, a yellow star will then appear next to the StreamHD Device Icon, making it the default device for future connections.

4. CONFIGURING VIDEO SETTINGS:


To configure the Video Settings in Mac OS X, open the System Preferences window. It can be opened by highlighting the Apple icon in the upper left hand side of the Toolbar and then selecting **System Preferences** from the drop down menu.



You can choose to set the StreamHD's video output to either **Extend mode** or **Mirror mode**. The default setting in Mac OS X when first connecting is **Mirror mode**. Using the **Arrangement** tab at the top of the Color LCD Window, you can switch between Mirror & Extended mode




Mirror mode duplicates the image on your computer screen on the external monitor



Extend mode extends your desktop space across multiple monitors.


To select the appropriate Display Resolution for each monitor, highlight the Display tab in both Display windows, then select from the available display resolutions. Usually the best resolution for each Monitor will be the highest available resolution shown.




5. CONFIGURING AUDIO SETTINGS:

With Mac OS X, audio playback can be from either the PC speakers or from the TV (or other external speakers), attached to the StreamHD. The default when connecting the StreamHD is the PC speakers. To use the StreamHD's connected device to playback audio, follow the below instructions.

Open **System Preferences** and select the **Sound** icon



There will be a choice between **Internal Speakers** and **USB PnP Sound Device**. Select USB PnP Sound Device to playback audio through the StreamHD's HDMI, 3.5mm or S/PDIF connections. Select **Internal Speakers** to playback audio through the PC speakers.



For full details of installations procedures and troubleshooting for all Mac® Operating Systems, refer to the installation manual available on the installation CD, or online at www.warpia.com/support

To Contact Support: support@warpia.com