


Measuring Guide


Furniture Sizes



Chair (seats 1)
outside arm to outside arm - 32 in. to 43 in.



Loveseat (seats 2)
outside arm to outside arm - 58 in. to 73 in.



Sofa (seats 3 or more)
outside arm to outside arm - 74 in. to 96 in.

Seat cushion styles

Box Cushion

One, two and three piece slipcovers in form fit and relaxed fit fabrics.





T-Cushion



One, two and three piece slipcovers in form fit and relaxed fit fabrics.



Form Fit and Relaxed Fit Arm Width Guidelines



Form Fit and Relaxed Fit Seat Width Guidelines




Wing Recliners and Wing Chairs

Form Fit Box Cushion Wing Recliner
Seat Width - 24"
Back Height - 45"

Fits both box cushion and wing recliners



Form Fit T-Cushion
Seat Width - 32"
Back Height - 45"




Relaxed Fit T-Cushion
Seat Width - 29"
Back Height - 42"




Recliners and Lift Recliners

Sure Fit Form Fit
78" to 88"



Medium Sure Fit Form Fit
68" to 78"



Large Sure Fit Form Fit
78" to 92"

Ottomans



Form Fit - 30"
Measure the longest side of ottoman


Relaxed Fit - up to 116"
Measure all 4 sides and add together

Furniture Covers

Standard Covers

Seat Widths

Chair 24"
Loveseat 48"
Sofa 70"




Back Lengths
39" or 46"

Deluxe Covers

Seat Widths

Chair 26"
Loveseat 52"
Sofa 76"



Back Length 50"
(longer arm length)

Chaise Covers

Seat Width - 34"
Seat Depth - 65"



Dining and Folding Chairs



Short Dining Chair Cover
Back Height up to - 42"
Seat Width - 18.5"



Long Dining Chair Cover
Back Height up to - 42"
Seat Width - 18.5"



Folding Chair Cover
Back Height up to - 32"
Seat Width - 15" square