

Router Label

The router label is located on the bottom of your SBR-AC1750. You may need the following label information to set up a wireless network connection:

- **Model** - Router model name
- **P/N** - Router part number
- **SSID** (Format: **SURFboard-XXXX**) Default name of your 2.4 GHz or 5 GHz wireless network. We recommend that you change the default network name or add more wireless networks.
*Note: See the **SBR-AC1750 User Guide** for information on changing the default network name and user password.*
- **WI-FI SECURITY KEY** - Needed to access a wireless network using a secure router. We recommend that you change the network name which is needed to add more wireless devices to your wireless network.
- **SN** - Router serial number

Notes

Write your additional wireless network names and passwords here for future reference:

SSID #1:

Wi-Fi Security Key #1:

SSID #2:

Wi-Fi Security Key #2:

SSID #3:

Wi-Fi Security Key #3:

SSID #4:

Wi-Fi Security Key #4:

Additional SID:

Add'l Wi-Fi Security Key:

If the label is not attached here, please refer to the bottom of your router.

© 2015 ARRIS Enterprises, Inc. All rights reserved.

ARRIS, SURFboard, and the ARRIS logo are all trademarks or registered trademarks of ARRIS Enterprises, Inc. Other trademarks and trade names may be used in this document to refer to either the entities claiming the marks and the names of their products. ARRIS disclaims proprietary interest in the marks and names of others.

No part of this publication may be reproduced or transmitted in any form or by any means without written permission from ARRIS Enterprises, Inc.

ARSVD01604-a 03/2015



Quick Start Guide


SURFboard® SBR-AC1750 Wireless Router

The SBR-AC1750 is a wireless router that provides secure high-speed Internet connectivity to the wired or wireless network devices on your home or small business network.

Note: For Internet connections, you must have a cable, DSL or Satellite Internet service provider (ISP) service connection to the Internet.

To customize your wireless network connection and other advanced router settings, see the **SBR-AC1750 User Guide** for more information. The guide is available online at the ARRIS Support website, www.arris.com/consumer.

In the Box



BEFORE RETURNING THIS PRODUCT TO THE STORE for any reason, please call ARRIS Technical Support for assistance: 1-877-466-8646.

Step 1

Test Internet Connection - Modem

Note: If you are installing a new modem (or other broadband connection device), please refer to the installation instructions provided with your modem before proceeding with the wireless router installation (see **Step 2**).

Perform the following Internet connectivity test to check the Ethernet connection between your modem and connected device, such as a computer or laptop:


- Make sure your modem is powered ON.
- Power ON and log in to the computer connected to your modem.
- Open a web browser on the computer (such as Internet Explorer, Google Chrome, Firefox, or Safari).
- Type a valid URL (such as **www.surfboard.com**) in the address bar and click or press **Enter**.

The ARRIS website should open. If it did not open, please contact your service provider to set up your Internet service.

Step 2

Connect Ethernet - Modem, Router & Computer

- Disconnect the existing Ethernet cable connection from your modem.
- Connect that Ethernet cable to one of the four white **Ethernet** ports on the rear of the SBR-AC1750.
- Connect the blue Ethernet cable (included) to the **Ethernet** port on the rear of your modem.
- Connect the other end of the blue Ethernet cable to the blue **WAN** port on your SBR-AC1750.



Step 3

Connect Power - Router

- Connect the power cord (included) to the **Power** port on the rear of your SBR-AC1750.
- Plug the power cord into an available electrical wall outlet.

Make sure the **Power, WAN, Wireless,** and connected **Ethernet** LEDs on the SBR-AC1750 front panel light up SOLID green.

If the **WAN** LED did not light up solid, check the **Ethernet** cable connection to make sure it is properly connected.

Step 4

Confirm Connection - Router

- Open a web browser (such as Internet Explorer, Google Chrome, Firefox, or Safari) on your computer or other device that is connected to the white Ethernet port on your SBR-AC1750.
- Type a valid URL (such as **www.surfboard.com**) in the address bar and then click or press **Enter**.

The ARRIS website should open.

- If your SBR-AC1750 fails to connect properly, please power cycle your modem to reset the IP addresses.
- If the website did not open, please reconnect your device directly to your modem and repeat **Step 1** above.
- If the website still fails to open, please contact your service provider for assistance.

Step 5

Connect and Confirm Your Wireless Connection - Router

- From your computer, click on the **Wireless Network Link** icon located on your Windows taskbar to open the wireless networks list.
- Scroll down and click on your wireless network name, **SURFboard-XXXX** (see **SSID** number listed on the router label).
- Select **Connect automatically** and then click **Connect** to complete the remaining wireless network entries (see router label for the **Wi-Fi Security key**).
- Click **OK** when done.

Step 6

Start the Router Web Manager

- Open any web browser on your computer, type **192.168.0.1** in the address bar and then press **Enter**.
- Type the default user name: **admin**.
- Type the default password: **password**.
- Click **Login** to open the web manager.