






PINZON™

B001CGMKA4 PASTA MAKER

OPERATION INSTRUCTIONS

Prepare the machine for use

1. Fix the machine onto the table with the clamp provided and insert the handle into the roller hole (A).
2. When using the machine for the first time, clean it with a dry cloth to remove any excess oil.
3. To clean the rollers, pass a small quantity of dough through them and then throw the dough away.
4. If you need to remove the cutting attachment from the machine, lift it up manually, making it slide along its tracks. To install attachments onto the machine, repeat this procedure.



Maintenance of the machine

1. During use, clean the scrapers underneath the smooth rollers every so often with a piece of kitchen paper (B).
2. Never wash the machine with water or in the dishwasher!
3. To clean the machine after use, use a brush or a wooden rod (C).
4. To clean the inside of the machine, remove the plastic protectors (D).
5. If necessary, put several drop of olive oil on the ends of the cutting rollers (E).
6. Do not insert knives or cloths in between the rollers!
7. After use, replace the machine and its accessories back into their original box.