

Wireless HDMI - WHD200 Quick Installation Guide

1

WHD200 Receiver

WHD200 Transmitter

HDMI Cable x 2

IR Repeater Cable

DC Power Adapter

USB Power Adapter

Quick Start Guide

Anchors x 2, Screws x 2

Remote

2

WHD200 Transmitter

HDMI 1 HDMI 2 HDMI OUT

1st HD TV

**

Lap Top

Satellite Box/
Cable Box

Games Console

3D Blu-Ray Player

Connect any HDMI enabled device to HDMI 1 and or HDMI 2. Only one source will be ACTIVE at a time. Press the button on top of the Transmitter to switch between sources connected to HDMI 1 and HDMI 2.

NOTE: The use of HDMI Out is optional and not necessary to use the HDMI Transmitter with any source connected to HDMI 1 or 2.

3

WHD200 Receiver

USB Power

HDMI OUT

2nd HD TV

HD Projector

When connecting a projector or 2nd HDTV to the receiver that is NOT 1080p, please make sure the output settings (resolution) of the source device match the projector or HDTV.

Example: If the source connected to the HDMI Transmitter is 1080p and the projector or HDTV connected to the HDMI receiver is 720p, please change the output settings (resolution) of the source to 720p.

4

WHD200 Receiver

HDMI OUT

10-20 s

WHD200 Transmitter

HDMI 1 HDMI 2 HDMI OUT

**When using Windows 7, Windows 8.1 or Windows 10 on a Desktop computer, Laptop, Ultrabook or Tablet you MUST configure Windows for dual display output under "Control Panel > Display > Change Display Settings". Failure to do so will result in no image on the Projector, HDTV or HDMI enabled Monitor that is connected to the WHD200's Receiver.