






Roomba Anatomy




Roomba Set-up

- 1 Place battery into Roomba Robotic Floorvac.
(press down on both ends)
- 2 Charge for 3 hours — while you're waiting, load batteries in your Virtual Wall and Remote.




- 3 Clean the floor of loose stuff like you would before using a traditional vacuum. If you don't vacuum over it, don't use Roomba over it (e.g., rug tassels, power and blind cords).



Roomba Set-up

- 4 Set up your Virtual Wall to keep Roomba where you want it and away from where you don't.



5 Battery Indicator




Color of Battery Indicator	Battery Status
Pulsing Amber	Charging
Green	Fully Charged
Amber	Partially Charged
Red	Almost Fully Discharged
Flashing Red	Fully Discharged



Roomba setup – Self-Charging Home Base


- 6 Set up the Home Base against a wall in a location with a clear approach and no obstructions in front.



- 7 When Roomba completes a mission or the battery is running low, it will find its way back to the Home Base and re-charge for the next mission. There will be times Roomba can't find its Home Base. If this happens, place Roomba on the Home Base or plug into the wall.


To manually send me back to recharge, I need to be placed within 4-5 feet in front of the Home Base. Then press both the "Clean" and "Spot" button at the same time.

- 8 To restart Roomba when it is on the Home Base, just press "Clean" and watch Roomba GO!



Roomba at Work

- 1 Place Roomba in the center of the room and press "Clean."
Roomba will automatically calculate how long it needs to clean your entire room.



or

- 2 Use "Spot" to intensively clean a 3 ft. diameter area.


Spot works great on spills or in high traffic areas.

- 3 Use "Max" for extended cleaning time. Roomba will clean for up to 120 minutes before shutting off.

- 4 "Dirt Alert" will illuminate when Roomba has detected dirt that requires special attention. When the dirt is gone, Roomba will continue in its standard cleaning mode.

In dirtier areas, I increase my cleaning intensity.




- 5 To pause Roomba, hit any button on the panel. To stop, pick it up.



Roomba at Work

- 6 When Roomba stops, check the indicator light.


Roomba stops for 3 reasons



If my mission is abandoned, pick me up and examine my brushes. Remove any obstructions before restarting.


- 7 When Roomba is not cleaning it is recommended that you keep it plugged in. That will help the battery stay in peak condition.

- 8 Use your remote to power up, start a cleaning cycle, direct Roomba to the dirt.




Keep Roomba Running


- 1 Empty the bin over a trash barrel after each use. Don't forget to remove the filter assembly and empty the 2nd chamber.



- 2 Remove and clean the brushes every 10 uses.




- 3 Inspect and wipe the sensors clean. (when you clean brushes)



Cotton swabs work great!

- 4 Inspect the vacuum inlet and clean debris as needed.

- 5 Change filters.



I recommend you do this every 2 months.



Roomba Last Thoughts

The Roomba Robotic Floorvac is easy to use,
but under the hood it's a complex robot. We're
Roboticians, the retailer is not. If you have
questions or comments, we're anxious to help.

Please visit us at
www.irobot.com


or
call 877-855-8593

iRobot, Roomba, Roomba Discovery, Virtual Wall and "if it's down there, we'll get it" are trademarks of iRobot Corporation.

© 2004 iRobot Corporation. All Rights Reserved

US Pat Nos 6,594,844 and 6,690,134. Additional Patents Pending
Burlington, MA 01803

Version: 4210-V1





Roomba

...smart
...simple
...clean

Model 4210