



BLUETOOTH HEADSET USER GUIDE

Contents

Specification.....2

Product indication.....3

Charging the headset.....5

Power on/off the headset.....6

Pair to your Smartphone.....7

Connect two Bluetooth devices at the same time.....8

Answering a call.....9

Ending a call.....9

Rejecting a call.....10

Redialing the last called number.....10

Microphone Mute.....10

Voice dialing.....10

Call switching.....11

Playing music.....11

1

Specification

Bluetooth Standard: Bluetooth V4.0

Frequency Range: 2.4GHz

Operation: Class2

Bluetooth Mode: Headset/handfree/A2DP/AVRCP

Operation Range: Up to 30 feet



Talk/Playing Time: Up to 8 hours

Standby Time: Up to 180 hours

Charging Time: 2.5 hours

2

Product indication



Charging the headset

You must charge the headset fully before using the headset for the first time.

1.Connect the USB charging cable to the USB charge port of the headphone.

2.The light indicator will turn into red when charging.

3.The full charge takes about 2.5 hours.

4.The red light indicator goes out and turn into green when charging completed.

Low-Voltage alert:

When the indicator turns into red and alert tone "battery low" sounds indicate that the battery has run out, need to charge as soon as possible.

5

Power on/off the headset

Power on:

Press the multifunction button about 3 seconds until the green indicator flash. You will also hear the indication voice "Power On".

Power off:

Press the multifunction button for about 3 seconds until the red indicator light flash and then goes off. You will also hear the indication voice "Power Off".

6

Pair to your Smartphone

- 1.**Press the multifunction button for about 5 seconds until the red and green lights start flashing alternately.
- 2.**Turn on the Bluetooth function of your phone.
- 3.**Search for the Bluetooth devices and select "Mpow Cheetah"
- 4.**Enter the code "0000" if needed.
- 5.**If pairing is successful, the green light indicator starts flashing. You will also hear the indication voice "Your headset is connected."

Remark:

- 1.** Please make sure the headphone is off before pair.

7

- 2.** It will connect to the pre-set phone automatically when turns on. (Please make sure the Bluetooth function of you phoe is on.)

Connect two Bluetooth devices at the same time

- 1.**Pair the Bluetooth headphone to the first phone.
- 2.**After pair successfully, turn off the headset, and also disable the Bluetooth function of the first phone.
- 3.**Pair the Bluetooth headphone to the second phone.
- 4.**After pair successfully, turn on the Bluetooth function of the first phone. Select the "Mpow Cheetah" and click "connect".
- 5.**Two phones will both connect the headphone at the same time.

8

Answering a call

For iPhone users:

Selection 1. Press the multifunction button.

Selection 2. Press the "Answer" button of your iPhone and check your iPhone call menu. Look for the audio source and select the headphone "MPOW cheetah".

For Android User (such as Samsung, HTC, Sony etc.):

Selection 1. Press the multifunction button.

Selection 2. Press the "Answer" button of your phone.

Ending a call

Selection 1. Press the multifunction button.

Selection 2. Press the answer key on your phone.

9

Rejecting a call

Selection 1. Press the multifunction button for about 2 seconds.

Selection 2. Press the end key on your phone.

Redialing the last called number

Double press the multifunction button.

Microphone Mute

During the call, press the " - " for 2 seconds, microphone is muted; press the " - " for 2 seconds again, microphone will work again.

Voice dialing

On the status of standby, long press "MFB" for about 3 seconds.

10

Call switching

Call switching between mobile phone and headset: during a call, press "V+" for about 2 seconds, the audio will be switched from the Bluetooth headset to mobile phone; Short press "MFB", the audio will be switched from mobile phone back to the Bluetooth headset.

Playing music

When you are listening to the music, you can press the buttons "Play, Pause, Previous Song, Next song" to select your optimal performance and control the volume.

- 1.**Play/Pause: Short press the multifunction button.
- 2.**Next Song: Long press the button " - " for 2 seconds.
- 3.**Previous Song: Long press the button " + " for 2 seconds.
- 4.**Volume Up: Short press the button " + ".
- 5.**Volume Down: Short press the button " - ".

11

Correct disposal of this product



(Waste Electrical & Electronic Equipment)
This marking shown on the product or its literature, indicates that it should not be disposed with other household wastes at the end of its working life.

To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources.
Household user should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take this item for environmentally safe recycling.
Business users should contact their supplier and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial wastes for

12

Contact us:

Website: www.xmpow.com
Email: support@xmpow.com