



Fliker



OWNER'S MANUAL

Version 2012/1

INDEX

• IMPORTANT SAFETY	
NOTICE.....	2
• SCOOTER PARTS AND COMPONENTS.....	4
• INSTRUCTIONS FOR	
ASSEMBLY	5
• CHECK BEFORE RIDING.....	7
• HOW TO RIDE YOUR FILKER SCOOTER.....	8
• USE AND MAINTENANCE GUIDE.....	9

NOTE: Any photos or decals of the scooter in the owner's manual are intended to be for reference only and there may be some differences to the item you have purchased.

IMPORTANT SAFETY NOTICE



WARNING



PRECAUTIONS:

Like any moving products, scooters can be dangerous if due care and attention is not paid. Be sure to read the manual before going on your scooter. In particular pay attention to the following:


IMPORTANT NOTICE TO PARENTS: This manual contains important information relating to your child's safety, it is your responsibility to review this information with your child and make sure they are fully aware of all the information and warnings within the manual. Please carefully read this manual before you commence assembly of this scooter and review this information with young riders before they ride.

1. Always wear protective equipment such as helmets, elbow pads and knee pads that comply with relevant safety standards. Correct clothing should be worn such as long sleeve tops and long pants.
2. Always wear the correct footwear. Feet should be fully enclosed. **DO NOT** wear incorrect footwear such as sandals, flip flops or heels while riding your scooter.
3. Only ride your scooter on flat and level ground. **DO NOT** use the scooter on wet or uneven ground. **DO NOT** ride the scooter on unsmooth areas with rocks and gravel. **DO NOT** ride your scooter at dusk or at night.
4. Always hold on with both hands while riding your scooter. **DO NOT** ride using only one hand.

5. **DO NOT** make sharp turns while riding your scooter; this may cause a fall and/or injury to you or a third party. **DO NOT** lean on the handlebars while turning as this will lessen your control and may cause a fall and/or injury to you or a third party.
6. **DO NOT** use your scooter in wet, slippery or icy conditions as this will lessen your control and may cause an injury and/or fall to you or a third party.
7. **DO NOT** ride the scooter down hills or slopes especially down long steep hills as this can cause damage to the scooter and may cause brake failure. This could cause an injury and/or fall to you or a third party.
8. Please test the brake on your scooter to make sure it is fully functioning before every use of your scooter. Please note that after prolonged use the brake may become hot so please **DO NOT** touch the brake after use in case of injury.
9. Please test that the handlebars are in good working condition before every use of your scooter. Make sure that the wheel turns correctly and smoothly and that the handlebar is fastened correctly before every use of your scooter.
10. Please make sure that all parts are fully assembled and tightened correctly before every use of your scooter.
11. You may see people online, on TV or on the street doing tricks or stunts with their scooters. Please **DO NOT** attempt to copy
12. Only ride your scooter under the direct supervision of an adult.
13. **DO NOT** ride your scooter on roadways.
14. Please obey any local laws when riding your scooter.
15. **DO NOT** modify your scooter in any way.
16. Fliker scooters are designed for single person use only.
17. Please adhere to the weight limit stated on the box.
18. IF ALL PRECAUTIONS ABOVE ARE NOT ADHERED TO
INJURY MAY BE CAUSED TO YOU OR A THIRD PARTY.

WARNING! For your safety there is an inbuilt system to stop the handlebars rotating 360°. If you turn the handlebars too sharply this may cause this to break and then snap the brake cable.

SCOOTER PARTS AND COMPONENTS




PARTS LIST


NO.	NAME	NO.	NAME
1	Hand Grip	7	Folding Knob
2	Handlebar	8	Brake Plate
3	Stem Cap for Handlebar	9	Front Wheel
4	Brake Lever	10	Action Deck
5	Brake Cable	11	Rear Wheel

ASSEMBLY INSTRUCTION

ADULT ASSEMBLY ONLY! Open the box and remove the scooter and all parts from the box. Please check the part list on the previous page to make sure that you have all the parts needed to assemble your scooter




STEP 1 UNFOLD SCOOTER



Undo the Velcro holding the scooter together. Hold the steering bar firmly and pull it away from the main body of the scooter so that it is standing upright. **WARNING!** Make sure your fingers are clear of the folding or pinch point. Screw in both knobs in a clockwise direction; please ensure that both


knobs are tightened completely.

STEP 2 Handlebar Assembly




Place the handlebar set onto the steering tube in the centre (Note the brake levers should be on the right). Cover the handle bar with the stem cap. Correct the angle of the handlebars and then screw in the bolts. Make sure the handlebar is securely fixed and cannot be moved forward or backwards.

STEP 3 FOLD SCOOTER



Grasping the steering tube tightly unscrew one of the knobs and then the other. **WARNING!** No one should be on the scooter while it is being disassembled. Push the handlebar down towards the footplates. Wrap the scooter with the Velcro band to secure it. **WARNING!** Make sure your fingers are clear of the folding or pinch point.

HOW TO CHANGE THE WHEEL




Position the front wheel in between fork plates, insert wrench through one side of plate and into wheel hole, insert the longer bolt from the other side of fork: remove wrench and insert the other bolt with washer. Tighten the bolt set with wrenches.

CHECK BEFORE RIDING


1. Please ensure the brakes are fully functional.
2. Please check that the scooter is correctly assembled and that all parts are sufficiently tightened.
3. Please check that the rear wheels are fully mobile and that the footplates are securely fastened.
4. Finally you can start to ride the scooter after checking the above points.
5. These points should be checked every time you ride.

HOW TO RIDE

1. Step on the footplates according to the image below.



2. Lower your body and sway from side to side. Repeat this action and the scooter will move forward easily.



USE GUIDE AND MAINTENANCE

1. After you have used the scooter for a week or two, the wheels will need to be checked to ensure they are still in perfect working order. To do so rotate the bearings and wheels and check if any lubrication or adjustments are needed.
2. Please do not use plastic to cover your scooter if it is being stored or transported as this may damage the finish. **DO NOT** use a wet cloth, alcohol, industrial cleaners or solvents to clean the scooter as this may result in loss of gloss, the removal of decals or dissolve the materials in the scooter. If the scooter loses its gloss a small bit of car wax can be used to polish the scooter.
3. In normal circumstances it is recommended that you disassemble, clean and lubricate the scooter every 6 months. Please take extreme care to ensure the scooter is reassembled correctly.
4. If the front fork, wheels and/or rear support frame are not correctly tightened you can use a wrench to tighten the bolts correctly. Please ensure to not over or under tighten the bolts.
5. Due to normal wear and tear the PU wheels and bearings may need to be replaced after some time. Please contact the place of purchase for new wheels. **DO NOT** use parts designed for other scooters, the use of anything other than Fliker parts may affect your safety.
6. If the brake cable becomes lose, please screw out the bolt and nut on the brake gear and pull the brake cable out with a clamp. Reposition the brake cable so that it is tense and screw the bolt

and nut onto the brake gear all the while keeping the cable taught.

7. Over time the nuts and bolts may become loose, please check that all nuts and bolts are sufficiently tightened before each use of your scooter.

NOTE: Please read this manual carefully and keep it for future reference. The dealer will not take responsibility if the scooter is used in a manner for which it was not intended or if all warnings which are stated in the manual are not followed.

Product is distributed by

ATM Sports LTD
6-9 Trinity Street Dublin 2 Ireland
Tel: +353 0818 333490
Fax: +353 0818 333491
www.fliker-scooter.co.uk